

1694 Operators Manual
9-9922

epcatalogs.com



THIS SAFETY ALERT SYMBOL INDICATES IMPORTANT SAFETY MESSAGES IN THIS MANUAL. WHEN YOU SEE THIS SYMBOL CAREFULLY READ THE MESSAGE THAT FOLLOWS AND BE ALERT TO THE POSSIBILITY OF PERSONAL INJURY OR DEATH.

IMPORTANT

If This Tractor Is Used By an Employee Or Is Loaned Or Rented, Make Certain That The Operator(s), prior To Operating:

- 1. Is Instructed In Safe And Proper Use.**
- 2. Reads And Understands The Manuals Relating To The Tractor.**

SAFE OPERATING INSTRUCTIONS

- | | |
|---|---|
| 1. SECURELY FASTEN YOUR SEAT BELT IF THE TRACTOR HAS A ROPS. | 6. DO NOT PERMIT OTHERS TO RIDE. |
| 2. WHERE POSSIBLE, AVOID OPERATING THE TRACTOR NEAR DITCHES, EMBANKMENTS, AND HOLES | 7. OPERATE THE TRACTOR SMOOTHLY NO JERKY TURNS, STARTS OR STOPS. |
| 3. REDUCE SPEED WHEN TURNING, CROSSING SLOPES, AND ON ROUGH, SLICK, OR MUDDY SURFACES. | 8. HITCH ONLY TO THE DRAWBAR AND HITCH POINTS RECOMMENDED BY TRACTOR MANUFACTURER. |
| 4. STAY OFF SLOPES TOO STEEP FOR SAFE OPERATION. | 9. WHEN TRACTOR IS STOPPED, SET BRAKES SECURELY AND USE PARK LOCK IF AVAILABLE. |
| 5. WATCH WHERE YOU ARE GOING, ESPECIALLY AT ROW ENDS ON ROADS | |

PER OSHA 1928 51

EMPLOYER SHALL NOTIFY EMPLOYEES WHO OPERATE AGRICULTURAL TRACTORS OF THESE INSTRUCTIONS AT INITIAL ASSIGNMENT AND ANNUALLY THEREAFTER.

Case Tractors Meltham HUDDERSFIELD England HD7 3AR

November, 1983 (Revised October 1985)

TABLE OF CONTENTS

TO THE OWNER	III	OPERATING INSTRUCTIONS	39
SAFETY	IV-XIX	Run-In Procedure	39
Safety Rules	IV	Before Operating the Tractor	40
Before Starting	V	Towing	41
Operation	IV	How to Transport the Tractor	41
Service	VIII	Operating Instruments	42,43
HAND SIGNALS	XX-XXI	Operating Lamps	44,45
DECALS	XXII-XXVI	Instrument Panel Controls	46-49
SERIAL NUMBERS	1	Air Conditioning Operation	50-53
DIESEL ENGINE SPECIFICATIONS	2,3	Foot Pedals	54,55
GENERAL SPECIFICATIONS	4	Levers, L/H Side	56,57
APPROXIMATE TRACTOR SPEEDS	8-11	Levers, R/H Side	58-63
FUEL SPECIFICATIONS	12	Controls Cab Roof	64,65
APPROXIMATE MEASUREMENTS	13	Controls Cab	66-68
APPROXIMATE TRANSPORT WEIGHTS	13	Operator's Seat	69
TIRE AND WHEEL EQUIPMENT	14,15	Seat Belt	70
FRONT TIRE POSITIONS	16	Auxiliary Outlet Socket	71
TIRE ALIGNMENTS	16	Operating the Engine	72
FRONT WHEEL TREAD POSITIONS	17-19	Starting Procedure	73,74
REAR WHEEL TREAD POSITIONS	20	Stopping the Engine	75,76
LUBRICATION	21-38	Cold Temperature Operation	77
Engine Hourmeter	21	Power Shift Transmission	78,79
Selection of Engine Oil	21	Hydraulic Oil Cooler	80
Capacities and Approved Lubricants	23-25	Power Takeoff	81-83
Lubrication Charts	22-27	Operating Safety (PTO)	84
Grease Fittings	28,29	Drawbar	85-87
Engine Oil Change	30	Drawbar With Pickup Hitch	88-91
Engine Oil Filter Change	31	Three Point Linkage	92
Transmission Oil Level Check and Change	32	Linkage Jeffes Type	93
Transfer Gear Box Oil Level	33	Lift Rod Adjustment	94
Steering Pump Filter Change	34	Leveling Lever Adjustment	95
Final Drives	34	Sway Blocks	96
Hydraulic Oil Filter Change	35,36	Mechanical Flotation	97
Differential Oil Level - MFD	37	Stabilizer Bar Adjustment	98
Front Hubs Oil Level - MFD	38	Top Link Adjustment	99
		Spacer Bar Adjustment	99
		Operating the Linkage	100,101
		Operating Jeffes Linkage	102
		Lower Link Sensing	103
		Operating Draft Equipment	105
		Operating Above Ground	106
		Operating External Equipment	107,115
		Hydraulic Hose Couplers	116
		Front Tread Adjustment	117
		Toe-In Adjustment	118,119
		Rear Tread Adjustment	120
		Tractor Ballast	121
		Front End Weights	122
		Rear Wheel Weights	123
		Liquid Ballast	124
		Measuring Rear Wheel Slip	125

MAINTENANCE	126-167
First Oil Change 20 Hours	127
Raising Engine Cover	128
Removing Front Panel	129
Removing Side Panels	130-131
Regular Maintenance Chart	132
Daily Inspection	133
50 Hour Service	134-137
100 Hour Service	138
200 Hour Service	139
400 Hour Service	140-147
800 Hour Service	148-154
Air Conditioning	155-160
Alternator	164
Auxiliary Battery	163
Battery	161,162
Fuses	169
Lamps	165-168

OPTIONAL EQUIPMENT	170
--------------------------	-----

PATENT NUMBERS	171
----------------------	-----

TO THE OWNER OF A CASE TRACTOR

Use this manual as your guide. If you follow the instructions given in this manual, your Case Tractor will work well for many years.

Your Authorized Case Dealer can give you assistance with J I Case Company made parts and persons with special training that know the best methods of repair and maintenance for your tractor.

Call your Authorized Case Dealer if you need any assistance or information. Put the name, address and phone number of your nearest dealer below.

Your Authorized Case Dealer



Figure 1

NOTE: When left-hand and right-hand are used in this manual, they are the same as your left and right when you are sitting in the tractor seat looking forward.

[Buy now](#)

[Case Tractor 1694 Operator's Manual PDF](#)

[With Instant Download](#)