

epcatalogs.com

4690 Tractor

Operators Manual

9-6805

Reprinted

CASE 



This symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED. The message that follows the symbol contains important information about your safety. Carefully read the message. Make sure you fully understand the causes of possible injury or death.

SB001

IF THIS MACHINE IS USED BY AN EMPLOYEE, IS LOANED, OR IS RENTED, MAKE SURE THAT THE OPERATOR UNDERSTANDS THE TWO INSTRUCTIONS BELOW.

BEFORE THE OPERATOR STARTS THE ENGINE:

1. GIVE INSTRUCTIONS TO THE OPERATOR ON SAFE AND CORRECT USE OF THE MACHINE.
2. MAKE SURE THE OPERATOR READS AND UNDERSTANDS THE OPERATOR'S MANUAL FOR THIS MACHINE.



WARNING

IMPROPER OPERATION OF THIS MACHINE CAN CAUSE INJURY OR DEATH.

BEFORE STARTING THE ENGINE, DO THE FOLLOWING:

1. READ THE OPERATOR'S MANUAL.
2. READ ALL SAFETY DECALS ON THE MACHINE.
3. CLEAR THE AREA OF OTHER PERSONS.

LEARN AND PRACTICE SAFE USE OF MACHINE CONTROLS IN A SAFE, CLEAR AREA BEFORE YOU OPERATE THIS MACHINE ON A JOB SITE.

It is your responsibility to observe pertinent laws and regulations and to follow manufacturer's instructions on machine operation and maintenance.

See your Authorized Case dealer for additional operator's manuals, parts catalogs, and service manuals.

TABLE OF CONTENTS

TO THE OWNER	III	OPERATING INSTRUCTIONS	34-127
SAFETY	IV-XVI	Run-In Procedure	34,35
Safety Rules	IV	Before Starting the Engine	36
Before Starting	IV-V	Towing	37
Operation	VI-XIII	Operating Instruments	38-43
Service	XIV-XVI	Operating Controls	44-81
HAND SIGNALS	XVII-XVIII	Steering Console	44-51
DECALS	XIX-XXIII	Steering Column Tilt	52
SERIAL NUMBERS.....	1	Moving the Telescopic	
DIESEL ENGINE SPECIFICATIONS ...	2,3	Steering Column	52
GENERAL SPECIFICATIONS	4-7	Operator's Console	53-63
APPROXIMATE TRACTOR SPEEDS ..	8,9	Hand Brake Control	64
APPROXIMATE OVER ALL		Heater Stop Valve	65
MEASUREMENTS	10	Fuel Tank Water Trap	65
APPROXIMATE TRANSPORT WEIGHT .	10	Cab Headliner Controls	66,67
OPERATOR'S CAB	11	Cab Air Flow Control	68
TIRE AND WHEEL EQUIPMENT	11	Cab Defroster Control	68
WHEEL TREAD POSITIONS	12-16	Cab Air Flow Arrangements	69-71
TIRE PRESSURE	16	Air Conditioner Operation	72
DUAL WHEELS	17	Cab Door Lock	72
FUEL SPECIFICATIONS	18,19	Ash Tray	72
LUBRICATION	20-33	Rear View Mirrors	73
Engine Hourmeter	20	Cab Window Lever	73
Diesel Engine	21	Operator's Seat	74-76
Lubrication Chart	22,23	Seat Belts	77
Engine Oil Change	24,25	Amber Warning Lamps, Direction	
Engine Oil Filters	25	Turn Signals & SMV	78,79
Rear Steering Valve Filter	26,27	Implement Warning Lamps &	
Rear Steering Hydraulic Oil Filter	28	SMV Symbol	80
Transmission Oil Level		Auxiliary Outlet Socket	81
Check & Change	29	Starting Procedure	82-84
Hydraulic Oil Filters	29,30	Stopping The Engine	84,85
Planetary Oil Level Check & Change .	31	Cold Temperature Operation	85
Differential Oil Level Check & Change .	32	Preparing Tractor For Operating in	
Tractor Brakes	33	Cold Temperatures	86
ALTERNATOR CHARGING SYSTEM ..	34	Cold Temperature Starting	87-90
		Coolant Heater	87
		Operating Cold Start Assist	88,89
		Starting Fluid	
		Container Replacement	90
		Power Shift Transmission	91,92
		Power Takeoff	93-95
		Operating PTO	93
		Guards	94
		PTO Operating Safety	95
		Drawbar	96
		Three Point Hitch System	97
		Hitch System Adjustments	98-100

TABLE OF CONTENTS

OPERATING INSTRUCTIONS

Hitch Operation	101-105
Hitch Control Lever	101
Electronic Hitch System	102,103
Controlling Maximum Depth	104
Stationary Depth Operation	104
Hydraulic Float Control	105
Anti-Sway Chain	105

Hitch Coupler - Category III	106
Remote Hydraulic Control	107-113
Remote Control Levers	107,108
Variable Flow Control	109,110
Operating the Remote System	111
Hydraulic Hose Couplers	112
Hydraulic Hose Coupling	113
Remote Cylinder	114
Hydraulic Cylinder Jack Stands	115
Wheel Rim Adjustment & Mounting	116
Wheel Spacing and	
Clamp Adjustment	117
Power Adjustable Wheel	
Mounting	118,119
Dual Wheel Mounting	120
Tire Mounting	121
Loading Machine to Tractor	121
Tractor Ballast	122-126
Measuring Slip	122
Tractor and Equipment Weight	123
Front End Weights	124
Wheel Weights	125
Tire Liquid Weight	126
Hood and Side Panels	127

PREVENTIVE MAINTENANCE ... 128-181

Cooling System	129-137
Pressure Cooling System	129
Coolant Solutions	130
Radiator Cleaning	130
Cooling System Service	131
Thermostat Check	132
Thermostat Replacement	132-134
Fan Belt Adjustment	135
Fan Belt Replacement	136
Water Filter and Conditioner	137

Fuel System	138-143
Service Intervals	138
Fuel Filter Replacement	139,140
Primary Fuel Filter	141,142
Air Removal	142,143

Air Induction System	144-153
Air Filter Service Interval	145
Final Air Filter Service	146-149
Aspirated Strata Tube Service	150-152
Tubes and Hoses	153

Neutral Start Switch Adjustment	154,155
---------------------------------------	---------

Parking Brake Adjustment	156
--------------------------------	-----

Electrical System	157-161
Head Lamps	157
Flood Lamps	157
Flashing Amber Warning Lamps	158
Rear Flood and Tail Lamp	158
Instrument Cluster Lamps	159
Fuse Panel	160
Head Lamp Adjustment	161

Storage Battery	162-164
When Batteries Are Not in Use	162
Battery Cables and Terminals	162
Battery Water	163
Vent Caps	163
Removal & Installation of Batteries	163
Auxiliary Battery Connections	164

Roll Over Protective Structure	
(ROPS)	165,166
Tractor Roll Over	166
Safety Rules	166
Maintenance and Inspection	166

Operator's Cab	167-181
Preventive Maintenance	167,168
Air Filter Removal	169
Air Filter Service	170,171
Seat Belt Inspection	
and Maintenance	171
Operator's Seat	172,173
Compressor Belt Adjustment	174
Compressor Belt Replacement	175
Compressor Belt Alignment	176
Refrigerant Check	177,178
Dome Lamp	179,180
Console Lamp	181

CASE TECHNICAL MANUALS 183

TO THE OWNER OF A CASE TRACTOR

Use this manual as your guide. If you follow the instructions given in this manual, your Case Tractor will work well for many years.

Your Authorized Case Dealer can assist you with Case Company made parts and persons with special training that know the best methods of repair and maintenance for your tractor.

Call your Authorized Case Dealer if you need any assistance or information.

Your Authorized Case Dealer



Figure 1

NOTE: When you are in the tractor seat looking forward, the right hand and left hand of the tractor are the same as your right and left hand.

[Buy now](#)

[Case 4690 Tractor PDF Operator's Manual](#)

[With Instant Download](#)