



EUROTECH CURSOR

EUROSTAR CURSOR

REPAIR MANUAL

epcatalogs.com

IVECO



This publication describes the characteristics, data and correct methods for repair operations on each component of the vehicle.

If the instructions provided are followed and the specified equipment is used, correct repair operations in the allotted time will be guaranteed, and the operators will also be protected against possible accidents.

Before any repair is commenced, ensure that all normal safety precautions are observed.

All items specified by the safety regulations-goggles, helmet gloves, boots-should be checked and worn.

All machining, lifting and conveying equipment should be inspected before use.

The data contained in this publication was correct at the time of going to press but, owing to possible modifications made by the Manufacturer for reasons of a technical or commercial nature or for adaptation to the legal requirements of different countries, some changes may have occurred.

Full or partial reproduction of the text and illustrations prohibited.

Publication Edited by:
IVECO S.p.A.
T.C.O. - B.U. Customer Service
Lungo Stura Lazio 49
10156 Torino (Italy)

Print **603.43.391** - 1st Ed. - 1999



Publication Produced by:
SATIZ S.p.A.
Pubblicazioni Tecniche Iveco
c/o Iveco - Lungo Stura Lazio 49
10156 Torino

NOTE

This manual is divided into several sections.

Section numbers are listed on the index page to be found at the beginning of each repair manual.


Each section deals generally with one of the main assemblies (engine, transmission etc.)

Each section deals with the following topics:

Specifications and data; Tightening torques; Special tools; Troubleshooting (fault diagnosis); Component removal/refitting; Repair operations.

This manual provides graphs and symbols instead of description of parts, operations or operating procedures (see next page).

Example



Ø 1 = Small end bushing bore dia.

Ø 2 = big end bearing bore dia.



Tighten to specified torque
Tighten to specified torque +
angular value

You will also notice that titles and subtitles of operations to be carried out are marked with a 6-figure number; the **Product Code** corresponding codes provided in the REPAIR BASE TIME SCHEDULES and in FAILURE CODES.

Below you will find the explanation of each "NUMERICAL CODE" component.

Product code:



PRODUCT



ASSEMBLY



SUBASSEMBLY
COMPONENT

Figures one and two identify the PRODUCT as part of the vehicle.


Example:

Product 50 = Chassis;

Product 52 = Axles;

Product 53 = Gearbox etc.

Assembly code:



PRODUCT



ASSEMBLY



SUBASSEMBLY
COMPONENT

Figures three and four identify the ASSEMBLY within the PRODUCT


Example:

Product 50 = Chassis;

Assembly 01 = Chassis frame;

Assembly 02 = Antitelescoping bumper etc.

Subassembly code:



PRODUCT



ASSEMBLY



SUBASSEMBLY
COMPONENT

Figures five and six identify THE SUBASSEMBLY and a Component of an Assembly within a PRODUCT.


Example:

Product 50 = Chassis;

Assembly 01 = Chassis frame;

Subassembly 40 = Chassis cross members etc.

Graphs and symbols

	Disconnection Disconnect		Reconnection Reconnect		Disassembly Dismantling		Assembly		Tightening torque		Tightening torque Tightening torque + angular value		Notching or caulking		Adjustment Regulation		Warning Note		Visual check Fitting position check		Measurement Dimension checking Check		Tooling		Machining surface Finished part		Interference Force fitting		Thickness Clearance, play, backlash		Lubricate Moisten Grease		Sealant Adhesive		Air bleeding		Suction, intake		Exhaust discharge		Operation	ϱ	Compression ratio		Tolerance Load unbalance		Rolling torque		Part replacement Original spare parts		Rotation		Angle Angle value		Preloading		Number of revolutions		Temperature		Pressure	$>$	Oversized Less than... Maximum, peak	$<$	Undersized Less than... Minimum		Selection Class Oversizing		Temperature below $< 0^{\circ}\text{C}$ Cold Winter		Temperature over 0°C Warm Summer
-----------------------------------------------------------------------------------	-----------------------------	-----------------------------------------------------------------------------------	---------------------------	-----------------------------------------------------------------------------------	----------------------------	-----------------------------------------------------------------------------------	----------	-----------------------------------------------------------------------------------	-------------------	-----------------------------------------------------------------------------------	--------------------------------------------------------	-----------------------------------------------------------------------------------	----------------------	------------------------------------------------------------------------------------	--------------------------	-------------------------------------------------------------------------------------	-----------------	-------------------------------------------------------------------------------------	----------------------------------------	-------------------------------------------------------------------------------------	--------------------------------------------	-------------------------------------------------------------------------------------	---------	-------------------------------------------------------------------------------------	------------------------------------	-------------------------------------------------------------------------------------	-------------------------------	-------------------------------------------------------------------------------------	----------------------------------------	-------------------------------------------------------------------------------------	--------------------------------	-------------------------------------------------------------------------------------	---------------------	-------------------------------------------------------------------------------------	--------------	-----------------------------------------------------------------------------------	-----------------	-----------------------------------------------------------------------------------	-------------------	-----------------------------------------------------------------------------------	-----------	-----------	-------------------	-----------------------------------------------------------------------------------	-----------------------------	-----------------------------------------------------------------------------------	----------------	-----------------------------------------------------------------------------------	------------------------------------------	-----------------------------------------------------------------------------------	----------	------------------------------------------------------------------------------------	----------------------	-------------------------------------------------------------------------------------	------------	-------------------------------------------------------------------------------------	-----------------------	-------------------------------------------------------------------------------------	-------------	-------------------------------------------------------------------------------------	----------	-----	--------------------------------------------	-----	---------------------------------------	-------------------------------------------------------------------------------------	----------------------------------	-------------------------------------------------------------------------------------	-----------------------------------------------------------	-------------------------------------------------------------------------------------	--------------------------------------------------------

INDEX

	Section
General	I
Engine	2
Clutch	3
Transmission*	4
Intarder - ZF hydraulic retarder	5
Propeller shafts	6
Rear axles	7
Axles	8
Suspension	9
Wheels and tyres	10
Steering system	11
Hydraulic system - Brakes	12
Scheduled Maintenance	13

[Buy now](#)

[Iveco Trucks EuroTech Cursor, EuroStar Cursor Repair Manual PDF](#)
[With Instant Download](#)