TOYOTA
INDUSTRIAL EQUIPMENT

epcatalogs.com

Service Manual

6HBW23

Serial Number 22,000 and up

TOYOTA

INDUSTRIAL EQUIPMENT

SERVICE MANUAL

4,500 lb. Powered Pallet Walkie

Model: 6HBW23

Serial No. 22,000 and up

epcatalogs.com

00700-CL340-2, Issued: 1 June 2004

epcatalogs.com

©2004 by Toyota Industrial Equipment.

All rights reserved. No portion of this manual may be reproduced mechanically, electronically or by any other means, including photocopying, electroinc retrieval or transfer, or recording without the written permission of the publisher.

Toyota Industrial Equipment believes the information in this manual is accurate and current as of the publication date; such information is subject to change without notice. Toyota Industrial Equipment is not responsible for any errors that may appear in the manual.

1012681A

Table of Contents

How To Use This Manual **1-1**
Map of the Manual 1-2
Manual Design 1-3
START Page 1-5
Safety **2-1**
Definitions 2-2
General Safety 2-3
Battery Safety 2-6
Jacking Safety 2-9
Towing 2-10
Welding Safety 2-11
Systems Overview **3-1**
Truck Model Identification 3-2
Vehicle Specifications 3-2
General Information 3-3
Special Tools 3-4
Theory of Operation 3-5
Planned Maintenance **4-1**
Maintenance Guidelines 4-2
Troubleshooting **5-1**
How to Use This Chapter 5-2
Electrical Troubleshooting Guidelines 5-3
Hydraulic Troubleshooting Guidelines 5-5
Definitions 5-6
List of Electrical Symbols 5-9
Control Handle Display and Programming 5-10
Service Display 5-21
Power Amplifier Fault Codes 5-24
Programmable Maintenance Tool (PMT) 5-26
List of Troubleshooting Charts/Tables 5-31
Troubleshooting Flowcharts 5-33
Symptom Tables: Lift/Lower System 5-37
Symptom Tables: Travel (Forward/Reverse) System 5-41
Component Procedures **6-1**
Component Locator Photo 6-3
Battery 6-4
Tractor Covers 6-9
Power Cables 6-10
Wiring Harness 6-11
Fuses 6-12
Circuit Breaker 6-13
Control Handle 6-14
Horn 6-18
Power Amplifier 6-19
Contactors 6-20
Master Control Relay 6-21
Switches (General) 6-23
Drive Unit 6-27
Electromagnetic Brake 6-33

epcatalogs.com

Motors, General 6-35
Drive Motor 6-42
Pallet Forks and Load Wheels 6-45
Hydraulic Components 6-47
Cold Storage Conditioning 6-55
Appendix A-1
Lubrication Equivalency Chart A-2
Torque Chart - Standard A-3
Torque Chart - Metric A-4
Decimal Equivalent Chart A-5
Standard/Metric Conversions A-7
Schematics A-9
Index I-1

epcatalogs.com

Buy now

Toyota Equipment 6HBW23 Service Manual PDF

With Instant Download