



Service Manual

Model TH255

S/N THS00100 & After

31200364

*Revised
February 8, 2012*

epcatalogs.com

epcatalogs.com

EFFECTIVITY PAGE

September 11, 2008 - A - Original Issue Of Manual

February 8, 2012 - B - Revised pages 1.3, 2.14 - 2.17, 3.4 - 3.6, 3.8, 4.2, 5.12, 5.13, 8.9, 8.10, 8.19 - 8.21, 8.27, 8.28, 8.33, 9.12 - 9.17, 9.33 - 9.47

epcatalogs.com

EFFECTIVITY PAGE

epcatalogs.com

SECTION CONTENTS

Section	Subject	Page
Section 1		
Safety Practices		1-1
1.1	Introduction	1-2
1.2	Disclaimer	1-2
1.3	Operation & Maintenance Manual	1-2
1.4	Do Not Operate Tags	1-2
1.5	Safety Information	1-2
1.6	Safety Instructions	1-3
1.7	Safety Decals	1-4
Section 2		
General Information and Specifications		2-1
2.1	Replacement Parts and Warranty Information	2-2
2.2	Torques	2-3
2.3	Specifications	2-11
2.4	Fluids, Lubricants and Capacities	2-13
2.5	Maintenance Schedules	2-15
2.6	Lubrication Schedule	2-18
Section 3		
Boom		3-1
3.1	Boom System Component Terminology	3-2
3.2	Safety Information	3-3
3.3	Boom System - Two Section Boom	3-3
3.4	Boom Assembly Maintenance	3-3
3.5	Boom Wear Pads	3-10
3.6	Quick Coupler Assembly	3-11
3.7	Forks	3-12
3.8	Boom Prop (If Equipped)	3-13
3.9	Emergency Boom Lowering Procedure	3-13
3.10	Troubleshooting	3-16
Section 4		
Cab and Covers		4-1
4.1	Operator Cab and Covers Component Terminology	4-2
4.2	Safety Information	4-3
4.3	Operator Cab	4-3
4.4	Cab Components	4-3
4.5	Cab Removal	4-8
4.6	Cab Installation	4-9

[Buy now](#)

[Caterpillar Telehandler TH255 Service Manual PDF](#)

[With Instant Download](#)