


# 8215 ENGINE

## SERVICE MANUAL



FORM 60406190  
8/92 REPRINT

[epcatalogs.com](http://epcatalogs.com)



**SUPPLEMENT No. 1**  
**8215 ENGINE SERVICE MANUAL**  
**604.06.190**

(5-88)

---

**ATTENTION:** Insert this sheet in the front of publication as record of receipt. Replace or add pages in the publication according to instructions below.

**Additional copies of this supplement are available. Please direct your request to:**

FIATALLIS NORTH AMERICA - Publications Services Dept.,  
701 Stevenson Drive - Springfield, IL 62703 U.S.A.

or

FIATALLIS EUROPE S. p. A. - Magazzino Stampati  
Viale Torino, 2 - 10040 Stupinigi (TO) Italy

---

REPLACE the following like pages:

Page 9 (Revised May, 1988)

Page 10 (No Change)

Any product change described in this publication is part of the continuing effort of Fiatallis to make its product responsive to customer need and is not to be construed as a field campaign. A product change may be incorporated with or without prior notice and without obligation to Fiatallis or its affiliates.

[epcatalogs.com](http://epcatalogs.com)

# 8215 Engine

## service manual

Form 604.06.190 English



### WARNING

STUDY THE OPERATION AND MAINTENANCE INSTRUCTION MANUAL THROUGH BEFORE STARTING, OPERATING, MAINTAINING, FUELING OR SERVICING THIS MACHINE.



The Operation and Maintenance Instruction Manual provides the instructions and procedures for starting, operating, maintaining, fueling, shutdown and servicing that are necessary for properly conducting the procedures for overhaul of the related components outlined in this Service Manual.



This symbol is your safety alert sign. It MEANS ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED.



Read and heed all safety instructions carrying the signal words WARNING and DANGER.



Machine mounted safety signs have been color coded yellow with black borders and lettering for warning and red with white borders and lettering for danger points.

[Buy now](#)

[FiatAllis Engine 8215 Service Manual PDF](#)

[With Instant Download](#)