

epcatalogs.com


72F Blade

Operators Manual

9-13960






REPRINTED



If Safety Decals on this machine use the words **Danger, Warning or Caution**, which are defined as follows:

- **DANGER:** Indicates an immediate hazardous situation which if not avoided, will result in death or serious injury. The color associated with Danger is RED.
- **WARNING:** Indicates an potentially hazardous situation which if not avoided, will result in serious injury. The color associated with Warning is ORANGE.
- **CAUTION:** Indicates an potentially hazardous situation which if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices. The color associated with Caution is YELLOW.

If Safety Decals on this machine are ISO two panel Pictorial, decals are defined as follows:

- The first panel indicates the nature of the hazard.
- The second panel indicates the appropriate avoidance of the hazard.
- Background color is YELLOW.
- Prohibitive symbols such as   and  if used, are RED.



WARNING

IMPROPER OPERATION OF THIS MACHINE CAN CAUSE INJURY OR DEATH. BEFORE USING THIS MACHINE, MAKE CERTAIN THAT EVERY OPERATOR:

- Is instructed in safe and proper use of the machine.
- Reads and understands the Manual(s) pertaining to the machine.
- Reads and understands ALL Safety Decals on the machine.
- Clears the area of other persons.
- Learns and practices safe use of machine controls in a safe, clear area before operating this machine on a job site.

It is your responsibility to observe pertinent laws and regulations and follow Case Corporation instructions on machine operation and maintenance.

TO THE OWNER OF A CASE IH FRONT BLADE

Use this manual as your guide. If you follow the instructions given in this Manual, your CaseIH Front Blade will work well for many years.

Your Dealer can give you assistance with replacement parts and persons with special training that know the best methods of repair and maintenance for your Front Blade.

Call your Dealer if you need any assistance or information.




YOUR AUTHORIZED CASE IH DEALER

NOTE: When you are in the tractor seat looking forward, the right hand and left hand of the tractor and of the attachment are the same as your right hand and left hand.


SERIAL NUMBERS

When parts or assistance are needed, or when writing to your Authorized CASE IH Dealer, always give this information.

1. Blade Model Number
2. Serial Number

J I Case A Tenneco Company Racine, Wisconsin 53404 U.S.A. <small>Marca Registrada</small>	Manufactured In U.S.A. 
Component / Attachment <small>THIS IS NOT A PIN (PRODUCT IDENTIFICATION NUMBER) PLATE</small>	
Model / Name _____	
Serial No. _____	

COMPONENT/ATTACHMENT
IDENTIFICATION NUMBER PLATE



Write the serial numbers of your blade on the lines below.

MODEL NUMBER _____

SERIAL NUMBER _____

TABLE OF CONTENTS

TO THE OWNER.	I	ASSEMBLE BLADE TO TRACTOR	
SERIAL NUMBERS	II	Connecting the Rear of the Blade	
TABLE OF CONTENTS.	III-IV	Mounting to the Tractor	11
SAFETY		Connecting the Front of the Blade	
Safety Rules	V	Mounting to the Tractor	12
Safety Messages.	VI	Assemble Cylinder Mounting Bracket	
SPECIFICATIONS	1	to 275 Tractor.	13
ADDITIONAL EQUIPMENT.	2	Install the Hydraulic Cylinder to	
UNPACKING	2-3	the 275 Tractor	14
PREPARATION OF THE TRACTOR		Assemble Cylinder Mounting Bracket	
Remove Implements	4	to the 245/255 Tractor	15
Installing Front Frame & Cover		Installing Hydraulic Hose & Quick	
Assembly On 275 Tractor	4	Coupler to 275 Tractor	16
Installing Front Mounting		Installing Hydraulic Cylinder to	
Anchor & Side Frame Supports		245/255 Tractors	17
on 245/255 Tractors	5	Installing Hydraulic Hose to 245/255	
PREPARATION OF THE BLADE		Tractor	18
Assemble Pivot Box to Blade	6	OPERATING INSTRUCTIONS	
Assemble Front Mounting		Before Operating the Blade	19
Bracket Assembly to "X"		Raising and Lowering the Front	
Frame	6	Blade	20
Installing the Lift Springs to		Angling the Front Blade	20
the Frame	7	Pushing Snow	20
Installing Front Mounting Frame		Light Grading	20
to Blade Assembly.	8	Heavy Grading	20
Adjust Rear Mounting Frame		Transporting	21
Assembly	9	Adjusting the Skid Shoes	21
Installing the Rear Mounting		Scraper Blade Wear.	22
Frame Assembly to the Front		After Operating	22
Mounting Frame Assembly	10	OPERATION OF OPTIONAL HYDRAULIC	
		ANGLING KIT.	38
		LUBRICATION	39

[Buy now](#)

[Case 72F Blade pdf Operation manual](#)

[With Instant Download](#)