



647781EN (31/01/2019)

MT 420 H 57K ST5 S1
MT 420 H TSS 57K ST5 S1
(RS4-14)

GEHL®

REPAIR MANUAL

DATE OF ISSUE	COMMENT
31/01/2019	- 1 st EDITION

Manitou BF S.A Limited liability company with a Board of Directors.

Head office: 430, Rue de l'Aubinière - 44150 Ancenis - FRANCE

Share capital: 39,548,949 euros

857 802 508 RCS Nantes.

Tel.: +33 (0)2 40 09 10 11

www.manitou.com

This manual is for information purposes only. Any reproduction, copy, representation, recording, transfer, distribution, or other, in part or in whole, in any format is prohibited. The plans, designs, views, commentaries and instructions, even the document organisation that are found in this document, are the intellectual property of MANITOU BF. Any violation of the aforementioned may lead to civil and criminal prosecution. The logos as well as the visual identity of the company are the property of MANITOU BF and may not be used without express and formal authorisation. All rights reserved.

GENERAL, CHARACTERISTICS AND SAFETY




00

ENGINE



10

TRANSMISSION



20

AXLE



30

BRAKE



40

BOOM



50

HYDRAULICS



70

ELECTRICITY



80

DRIVER'S CAB



85

FRAME - BODYWORK



90

OPTIONS - ATTACHMENTS



110

INTERACTIVE REPAIR MANUAL

MOTORISATION	
TABLE DES MATIÈRES	
10.1 CARACTÉRISTIQUES ET SPÉCIFICATIONS MOTEUR	17
10.1.1 CARACTÉRISTIQUES MOTEUR	17
10.1.2 SYNOPTIQUE MOTEUR	17
10.1.3 RÉGÉNÉRATION	17
10.2 LOCALISATION COMPOSANTS MOTEUR	17
10.2.1 ÉLÉMENTS MOTEUR	17
10.2.2 CIRCUIT REFROIDISSEMENT TRANSMISSION	17
10.2.3 ADMISSION ET ÉCHAPPEMENT	17
10.3 CONTRÔLE ET RÉGLAGE MOTEUR	17
10.3.1 DÉPOSE VALVE EGR	18
10.3.1 DÉPOSE INJECTEURS	19


647999FR
10 - 14/06/2015

MOTORISATION 19

10.1.1 DÉPOSE INJECTEURS


Pour retirer les quatre injecteurs (1, 10 - 5) :

- Effectuer la dépose de la valve EGR (2, 10 - 5) :
(→ 10.1.1 DÉPOSE VALVE EGR, 18)
- Retirer la durit (3, 10 - 5), clé de 7.



18 MOTORISATION 647999FR
10 - 14/06/2015

10.1.1 DÉPOSE VALVE EGR



- Mettre un bac sous le caisson moteur.
- Retirer les vis (2, 10 - 1) de fixation du tube (2, 10 - 1).
- Retirer la vis (3, 10 - 1) de fixation du tube (4, 10 - 1).
- Retirer les deux vis (5, 10 - 1) de fixation du tube en accordéon (6, 10 - 1).
- Défaire le collier (7, 10 - 1), desserrer la vis (8, 10 - 1).

LIST OF ABBREVIATIONS

°	Angle degree
Ω	Ohm: unit of electrical resistance, equal to V.A ⁻¹ .
A	Ampere: unit of measurement for electrical current intensity. It is one of the basic International System (SI) units.
AOC	Ammonia Oxidation Catalysts: elimination of the excess ammonia (NH ₃) by oxidation from combustion gases having undergone selective catalytic reduction (SCR) of nitrogen oxides (NOx), by injection of DEF.
APC	After Power Contact: positive power supply after switching on the ignition.
BMEP	Bloc Manipulateur ÉlectroProportionnel - Electro-proportional joystick unit: controls the hydraulic movements of lowering, lifting, tilting and digging by electronic sensors.
CAN	Controller Area Network: control communication network for inter-system communication (1939, Open, etc.).
CO	Carbon Monoxide: colourless, odourless and highly toxic gas.
CRC	Control Rôle Control: Boom suspension.
CVT	Continuous Variable Transmission.
DEF	Diesel Exhaust Fluid: aqueous solution consisting of 32.5% urea and 67.5% demineralised water, used to transform 85% of pollutants (NOx) into water vapour (H ₂ O) and harmless nitrogen (N ₂).
DOC	Diesel Oxide Catalyst: part of the exhaust gas filter or a post-treatment device used to reduce polluting emissions (HC and CO).
DPF	Diesel Particulate Filter : < FAP.
DSB	Double Switch Board: smart double switch board connected to a LIN network via a wiring harness.
DTC	Diagnostic Trouble Code: fault codes
ECM/ECU	Electronic or Engine Control Module/Unit : ECU making it possible to control the machine or the engine.
EGR	Exhaust Gaz Recirculation : Exhaust gas recirculation circuit to intake to reduce oxygen supply and reduce NOx.
FAP	Filtre À Particule (= Diesel Particulate Filter): filtration system used to trap fine particles, carcinogenic for humans, contained in combustion gases, particular from wood fires and Diesel engines.

[Buy now](#)

[Manitou MT420H Repair Manual PDF](#)

[With Instant Download](#)