

### MANITOU NORTH AMERICA, INC.

6401 IMPERIAL DRIVE Waco, TX 76712-6803

**NOTE:** Manitou Forklift Manuals are configuration updated and subject to change without prior notice. If your Forklift Mount of parts are not found in this manual, please contact your dealer or the first item. North America Parts Department for the latest information and parts availability.

# MRT1850

**PARTS MANUAL** 

For Parts Orders contact your Manitou North America Dealer or call:

Manitou North America, Parts Dept. 800-425-3727 or (254) 799-0232

Parts Dept. Fax: (254) 867-6504 Website: www.manitou-na.com

## **IMPORTANT**

### **PARTS LISTS:**

The text pages have a figure (for example: 1) printed in the top left corner, and a plus sign (+) at the bottom of the text pages have a figure (for example: 1) printed in the top left corner, and a plus sign (+) at the bottom of the text pages have a figure (for example: 1) printed in the top left corner, and a plus sign (+) at the bottom of the text pages have a figure (for example: 1) printed in the top left corner, and a plus sign (+) at the bottom of the text pages have a figure (for example: 1) printed in the top left corner, and a plus sign (+) at the bottom of the text pages have a figure (for example: 1) printed in the top left corner, and a plus sign (+) at the bottom of the text pages have a figure (for example: 1) printed in the top left corner, and a plus sign (+) at the bottom of the text pages have a figure (for example: 1) printed in the top left corner, and a plus sign (+) at the bottom of the text pages have a figure (for example: 1) printed in the text pages have a figure (for example: 1) printed in the text pages have a figure (for example: 1) printed in the text pages have a figure (for example: 1) printed in the text pages have a figure (for example: 1) printed in the text pages have a figure (for example: 1) printed in the text pages have a figure (for example: 1) printed in the text pages have a figure (for example: 1) printed in the text pages have a figure (for example: 1) printed in the text pages have a figure (for example: 1) printed in the text pages have a figure (for example: 1) printed in the text pages have a figure (for example: 1) printed in the text pages have a figure (for example: 1) printed in the text pages have a figure (for example: 1) printed in the text pages have a figure (for example: 1) printed in the text pages have a figure (for example: 1) printed in the text pages have a figure (for example: 1) printed in the text pages have a figure (for example: 1) printed in the text pages have a figure (for example: 1) printed in the text pages have a figure (for example:

"1" means that this is the first page of text or part no.s.

"+" means that the parts list is continued onto the next page. The last page does not have the "+" sign.

"X" in the Quantity columns means according to need.

### **PARTS ORDER:**

When placing an order, always state:

- Spare part ref. number
- Complete description
- Quantity
- Type of machine
- Machine serial number
- Component identification put by (mast, boom, cab, engine, axle, etc.)

### **NOTICE:**

Certain parts, or part assemblies i'ustra ed in this catalogue are supplied only as options, and not with th

## From Servin. (beginning with Serial No.) Up to Servin No. (ending with Serial No). For Serial No.s (used on Serial No.s only) Cept for Serial No.s (excluding Serial No.s) See parts page . . .



Up to machine Serial No., engine No., cab No., transmission No., etc.

From machine Serial No., engine No., cab No., transmission No., etc.

### ALPHABETICAL CONTENTS MRT1850T PARTS 547559 (R/04-01)

ACCELERATOR CABLE ASSEMBLY - 1520

AIR INTAKE SYSTEM - 20

ALTERNATOR - 870

ATTACHMENT, PIVOT - 1560

ATTACHMENT, PIVOT - 1570

AXLE HOUSING, FRONT (from Serial No. Z – ITA - 733764) – 440B

AXLE HOUSING, FRONT (from Serial No. Z - ITA - 738242 to Z-ITA-733763) – 440A

AXLE HOUSING, FRONT (to Serial No. Z - ITA - 738241) - 440

AXLE HOUSING, REAR (from Serial No. Y – ITA – 738164 to Z – ITA – 738216) – 450A

AXLE HOUSING, REAR (from Serial No. Z – ITA – 733746) – 450C

AXLE HOUSING, REAR (from Serial No. Z – ITA – 738217 to Z – ITA – 733745) – 450B

AXLE HOUSING, REAR (to Serial No. Y – ITA – 738163) - 450

BASKET ATTACHMENT, PENDULUM FCR. -1 380

BASKET ATTACHMENT, ROTATING F FNL 'LUM FORK (from Serial No. 8511 – 1525 G, including 8383 – 150040, 8490 – 148559, excluding 577 – 152563) – 1690A

BASKET ATTACHMENT ROTA ING PENDULUM FORK (to Serial No. 8510 140387, including 8577 – 152563, excluding 83' 3 150040, 8490 – 148559) – 1690

BASKET ROTAT, N LEDUCTION UNIT (from Serial No. 8511 – 1, 85.5, including 8383 – 150040, 8490 – 148559, evalueing 8577 – 152563) – 1710A

BASKET O ATION REDUCTION UNIT (to Serial No. 8510 – 148587, including 8577 – 152563, excluding 8383 – 150040, 8490 – 148559) – 1710

BASKET, PENDULUM - 1730

BODY, MUD GUARD - 30

BRAKE CIRCUIT AND ACCELERATOR (from Serial No. 9310 – 157765 including 9020 – 154271, 9187 – 158248, 9251 – 157708, 9254 – 157711, excluding for 9364 – 161250) – 100A

BRAKE CIRCUIT AND ACCELERATOR (from Serial No. 9310 – 157765, including 9020 – 154271, 9187 – 158248, 9251 – 157708, 9254 – 157711, except 9364 – 161250) - 100

BRAKE DISCS, FRONT AXLE (to Serial No. Z – ITA – 738164) - 500

BRAKE DISCS, FRONT AXLE (from A – ITA – 765651) – 500D

BRAKE DISCS, FRONT AXLE (from Serial No. Y – ITA – 738165 to Y – ITA – 766557) – 500A

BRAKE DISCS, FRONT AXLE (from Serial No. Y – ITA – 766558 to Z – ITA – 733763) – 500B

BRAKE DISCS, FRONT AXLE (from Z – ITA – 733764 to A – ITA – 765650) – 500C

BRAKE DISCS, REAR AXLE (from Serial No. Y – ITA – 766552 to Z – ITA – 733745) – 510A

BRAKE DISCS, REAR AXLE (from Serial No. Z – ITA – 733746) – 510B

BRAKE DISCS, REAR AXLE (to Serial No. Y – ITA – 766551) - 510

F 1KL LEVER ASSEMBLY - 240

L PAKE LEVER INSTALLATION - 70

CAB MISC. COMPONENTS II (from Serial No. 8315 – 148520, including 8073 – 143103, 8066 – 141853, 8072 – 143102, 8080 – 141839) – 62A

CAB MISC. COMPONENTS II (to Serial No. 8311 – 149140, excluding 8073 – 143103, 8066 – 141853, 8072 – 143102, 8080 – 141839) - 62

CAB, DOOR ASSEMBLY (from Serial No. 8315 – 148520, including 8073 – 143103, 8066 – 141853, 8072 – 143102, 8080 – 141839) – 63A

CAB, DOOR ASSEMBLY (to Serial No. 8311 – 149140, excluding 8073 – 143103, 8066 – 141853, 8072 – 143102, 8080 – 141839) - 63

CAB, MISC. COMPONENTS I (from Serial No. 8315 – 148520, including 8073 – 143103, 8066 – 141853, 8072 – 143102, 8080 – 141839) – 61A

CAB, MISC. COMPONENTS I (to Serial No. 8311 – 149140, excluding 8073 – 143103, 8066 – 141853, 8072 – 143102, - 8080 – 141839) - 61

CAB, MISC. COMPONENTS III (from Serial No. 8315 – 148520, including 8073 – 143103, 8066 – 141853, 8072 – 143102, 8080 – 141839) – 64A

CAB, MISC. COMPONENTS III (to Serial No. 8311 – 149140, excluding 8073 – 143103, 8066 – 141853, 8072 – 143102, 8080 – 141839) – 64

CAB, OVERHEAD (to Serial No. 8311 – 149140, excluding 8073 – 143103, 8066 – 141853, 8072 – 143102, 8080 – 141839) - 65

CAB, PRIMARY ASSEMBLY (from Serial No. 8315 148520, including 8073 – 143103, 8066 – 141853, 8072 – 143102, 8080 – 141839) – 60A

Buy now

Manitou Forklift MRT1850 Parts Manual PDF

With Instant Download