elecatalogs. colfi

100 Tractors

Operators Manual

1004459R2

Reprinted



This symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED. The message that follows the symbol contains important information about your safety. Carefully read the message. Make sure you fully understand the causes of possible injury or death.

SB001

IF THIS MACHINE IS USED BY AN EMPLOYEE, IS LOANED, OR IS RENTED, MAKE SURE THAT THE OPERATOR UNDERSTANDS THE TWO INSTRUCTIONS BELOW.

BEFORE THE OPERATOR STARTS THE ENGINE:

- 1. GIVE INSTRUCTIONS TO THE OPERATOR ON SAFE AND CORRECT USE OF THE MACHINE.
- 2. MAKE SURE THE OPERATOR F. ALS AND UNDERSTANDS THE OPERATOR'S MANUAL FOR THIS . 'AL' HINE.



IMPROPER OPE TILL C THIS MACHINE CAN CAUSE INJURY OR DEATH.

BEFORE STA. TING THE ENGINE, DO THE FOLLOWING:

- 1. READ ILE OPERATOR'S MANUAL.
- 2. F. AD ALL SAFETY DECALS ON THE MACHINE.
 - LAR THE AREA OF OTHER PERSONS.

LE IRN AND PRACTICE SAFE USE OF MACHINE CONTROLS IN A SAFE, LEAR AREA BEFORE YOU OPERATE THIS MACHINE ON A JOB SITE.

It is your responsibility to observe pertinent laws and regulations and to follow manufacturer's instructions on machine operation and maintenance.

See your Authorized Case dealer for additional operator's manuals, parts catalogs, and service manuals.

© 1995 Case Corporation

CASE and IH are registered trade marks of Case Corporation



McCORMICK FARMALL 100 and INTERNATIONAL 100 TRACTORS

Operator's Manual

Form No. 1 004 459 R2

CASE CORPORATION

TO THE OWNER

The purpose of this manual is to assist you in realizing the benefits you anticipated when you purchased this International Harvester product. Literally thousands of people have contributed to the design and production of this product and its delivery to you. They have an interest in its successful performance and have provided this manual to give you the benefit of the experience they have gained through years of field testing and normal usage of this and similar products.

The way you operate and the care you give this roduct will have much to do with its successful performance. This manual has been corefully prepared and the information arranged and illustrated to make it as easy as possible for you to find the information you wish. It will pay you to read the entire manual carefully before operating and keep it handy for future reference. Your International carefully before will be glad to answer any further questions you may have on the operation or care of this product.

It is the policy of Int. All the do so. We reserve the right to make changes or add improvements at any time w. Your incurring any obligation to make such changes on products sold previously.

All illustrations and descriptive matter in this publication apply to International Harvester products sold under the International, McCormick, McCormick-International, McCormick-Deering, or McCormick-Deering International trade name.

As a member of the National Safety Council, we are privileged to use the Green Cross for Safety to designate not only our interest in Farm Safety, but to point out more clearly the safety precautions in this manual.

IMPORTANT FUEL SYSTEM SAFETY WARNING AND ANNOUNCEMENT OF FREE, REPLACEMENT GASOLINE CAP



CAUTION! The following information pertains to personal safety. Be sure to read and follow these instructions.

PROBLEM — Gasoline vapors can build up pressure in your gasoline tank.

All gasoline fuels are more volatile today that ever before. They vaporize and build up pressure in your gasoline tank more easily than not past. Winter grade gasoline is especially tupic to vaporization and pressure build-up value and on hot Spring or Fall days. If you have a value to which is out of tune or not properly in aint lined, it can run hotter and increase vaporization.

DAMES — Fire and personal injury.

If the ruel cap is removed when the gasoline tank is hot and vapor pressure has, under certain circumstances built up in the tank, this sudden release of pressure could force gasoline out of the tank. If the gas cap is not fully secured and tightened, it could come off the tank, and again, gasoline could escape. This sudden eruption of gasoline exposes the operator to, and may cover him with, liquid fuel and vapors and is a clear fire hazard if a source of ignition is present. A running engine is a source of ignition, as are cigarettes, open flames, sparks a poorly maintained exhaust system. An immediate fire could occur. The operator or anyone in the area could be burned and suffer serious injury or even death.

RECAUTIONS — Observe the following steps for safe operation:

- Always tighten gas caps securely.
- Never, under any circumstances, take the gas cap off a hot or running tractor.
- Never hold over Winter gasoline for use in the Spring. Remove any equipment unnecessary for warm weather operations, such as comfort covers, heat housers, or radiator covers.
- Maintain equipment properly and pay particular attention to electrical, exhaust, fuel, and cooling systems. Repair or replace frayed electrical wires; leaky exhaust manifolds, gaskets, pipes and mufflers; damaged carburetors, sediment bowls and fuel lines. Be sure radiators are clean inside and out. Clean off any accumulation of trash, oil or grease.
- Make sure that fuel cap vent holes are not plugged, gaskets are in good condition, and that cap tangs are firmly riveted. Repair worn, bent, or deformed filler necks and damaged heat shields or shield insulation. If your tractor is not equipped with a heat shield or insulation, install such equipment on applicable models.
- Be alert to any unusual sights and sounds during operation. If you suspect everheating or pressure build-up in the fuel system, do not touch the cap. Turn off the engine and allow the tractor to cool before you touch the cap.

Buy now

Case 100 Tractors PDF Operator's Manual

With Instant Download