

OPERATOR'S MANUAL TIGERCAT H822 HARVESTER

TABLE OF CONTENTS

ISSUE 1.1, SEPTEMBER 2004

	SECTION
INTRODUCTION	iii
NON-APPROVED FIELD PRODUCT CHANGES	iv
SAFETY	1
CONTROLS AND OPERATION	2
LUBRICATION AND MAINTENANCE	3

epcatalogs.com

H822-OM00

H822 Harvester Available Literature

Operator's Manual, English (this manual)	Part No. 23598A
Parts Catalog	Part No. 23597A
Hydraulic Adapters Book	Part No. 1472A
Hydraulic Hose Assemblies Book	Part No. 3707A

Tigercat®

Tigercat Industries Inc.
P.O. Box 544
Paris, Ontario
Canada N3L 3T6

Tel: (519) 442-1000 Fax: (519) 442-1855

epcatalogs.com

Tigercat H822 Harvester

INTRODUCTION

An Operator's manual, Service manual and a Parts catalog are made available by **Tigercat** to assist the dealer, customer and operator in becoming familiar with the features of the H822 Harvester serial numbers 822H0123 and 82230191 to 82230999.

The operator's manual will assist the operator with the techniques of proper and safe operation of the H822 Harvester. There is also important information regarding the safe operation of the attachment. The service manual contains safety and servicing procedures and a preventive maintenance schedule to ensure optimum machine performance.

Section 1 in both the operator's manual and the service manual contains safety information that must be followed. As well, throughout the rest of the manuals, WARNING and CAUTION notices are displayed where necessary, drawing attention to possible hazards when performing certain procedures.

Only trained personnel should be allowed to operate or work on the machine.

The information contained in this manual is current at time of printing. Improvements to the machine are on-going and may not be covered, therefore in these cases contact your **Tigercat** dealer for the appropriate information.

The phrase “**and up**” appearing in this manual after the serial number implies that the related information is current for any machine serial number HIGHER than the serial number preceding the “**and up**”.

Tigercat reserves the right to make changes to the machine after this manual release date that may not immediately appear in this manual.

Every effort is made to send out updates on a regular basis. If the machine in question was built after the release date of this manual and there is a discrepancy, call Tigercat service department. The release date appears on the first page.

The Company reserves the right to change information contained herein at any time without prior notice.

Tigercat Industries Inc.



NON-APPROVED FIELD PRODUCT CHANGES

The installation of any unauthorized attachment or changes made of any kind to this **Tigercat** product could affect the product's ability to perform as originally intended. The product's integrity, stability and its ability to perform safely could be at serious risk.

IT IS **Tigercat** POLICY THAT NO CHANGES ARE TO BE MADE TO ITS PRODUCTS INCLUDING DELETIONS OR ADDITIONS OTHER THAN A **Tigercat** APPROVED OPTION FITTED IN THE FACTORY APPROVED MANNER.

Official approval to make changes or install options is **only** to be undertaken as follows:

- i) The relevant options for that product must be shown or listed on current **Tigercat** documentation or literature such as a printed specification sheet, price list, parts manual, or product literature issued by **Tigercat**.
- ii) Approved options or product changes authorized in writing by the **Tigercat** Engineering Manager.

AUTHORIZATION BY ANY OTHER PERSON IS UNACCEPTABLE.

Unauthorized changes made or contributed to by a person or organization may result in creating a dangerous situation and therefore the person or organization will be considered to have assumed the risk involved or be negligent in having created this situation.

Weight is an important factor when considering the addition of options or an attachment. Refer to your **Tigercat** distributor for information on maximum permissible operating weight and the effect the addition of various options may have on your machine.

Tigercat will not be held responsible for any situation that may arise resulting from Non-approved Field Product Changes to its product.

Should **Tigercat** become involved in a dispute resulting from changes made to the product without proper authorization by **Tigercat** as stated above, **Tigercat** will take whatever action is appropriate to protect its interests.

The product warranty policy and the certification on any safety items installed on the modified product will become NULL and VOID if the above policy is not adhered to as specified.

Non-approved product changes also nullify warranties given to **Tigercat** by its component manufacturers.

Tigercat Industries Inc.

Tigercat H822 Harvester

SECTION 1 - SAFETY

AUGUST 2004

**Read and understand this safety section prior to operating any equipment.
Read and understand all manuals for any attachment or accessories.**

CONTENTS - SECTION 1

BATTERY SAFETY	1.8
CAB EXITS	1.9
COOLING SYSTEM	1.16
EMERGENCY CAB EXITS	1.9
ENGINE DOORS	1.17
ER BOOM SYSTEM PRECAUTIONS	1.16
EXHAUST FUMES	1.17
FIRE PREVENTION	
FIRE PREVENTION GUIDELINES	1.18
WHAT ELSE TO DO BEFORE YOU EXPERIENCE A FIRE	1.19
WHAT TO DO AFTER A FIRE	1.20
WHAT TO DO IN CASE OF A MACHINE FIRE	1.19
FLUID LEAKS	1.15
HARVESTING ATTACHMENT - GENERAL SAFETY	1.12
HAZARD ZONE	1.5
HYDRAULIC PRESSURE HAZARD	1.15
LOOSE CLOTHING HAZARD	1.16
PARKING ROOM	1.16
PARKING THE MACHINE	1.13
PROTECTIVE CLOTHING	1.5
SAFETY INTERLOCK SWITCHES ON CAB DOORS	1.10
SAFETY PRECAUTIONS, GENERAL	1.5
SAFETY PRECAUTIONS, OPERATING	1.9
SAFETY PRECAUTIONS, SERVICING	1.14
SAFETY SYMBOLS	1.4
SIGNAL WORDS	1.4
WELDING, PRIOR TO	1.14
WORKING WITH OIL	1.6

[Buy now](#)

[Tigercat Harvester H822 Operator's Manual PDF](#)

[With Instant Download](#)