



epcatalogs.com

CONTENTS I

• Before Use

• CONTENTS II

• PARTS NAME INDEX

• 67Z7B

• ENGINE

Air Heater Starting Aid	1
Agency Approval	3
Rear Gear Housing	5
Cylinder Block Plumbing	7
Cylinder Block	9
Crankshaft	11
Valve Tappets	15
Crankcase Breather	17
Crankcase Breather Plumbing	19
Crankcase Breather Mounting	21
Vibration Damper	23
Drain Location	25
Rear Gear Train Mounting	27
Thermostat	29
Alternator	31
Alternator Mounting	33
Exhaust Recirculation	35
Exhaust Recirculation Air Plumbing	37
Exhaust Recirculation Water Plumbing	39
Fan Drive	41
Fan Drive Mounting	43
Fuel Drain Plumbing	45
Fuel Filter Location	47
Fuel Filter Plumbing	49
Fuel Filter Mounting	51
Flywheel Housing	53
Fuel Inlet Fitting	55
Fuel Pump	57
Fuel System Accessories	59

Fuel Plumbing	61
Flywheel Mounting	63
Flywheel	65
Front Gear Cover	67
Cabin Heater Plumbing	69
Auxiliary Pump Mounting	71
Auxiliary Cooling Plumbing	73
Air Intake Connection	75
Air Intake Manifold	77
Air Transfer Connection	79
Lifting Arrangement	81
Lifting Bracket Mounting	83
Oil Fill Labeling	85
Engine Oil Cooler	87
Full Flow Oil Filter	89
Oil Level Gauge	91
Lubricating Oil Pump	93
Oil Fill Arrangement	95
Hand Hole Cover	97
Oil Pan	99
Accessory Drive Pulley	101
Aftertreatment Device	103
Engine Control Module	107
Connecting Rod And Piston	109
Camshaft	111
Cylinder Head	113
Injector	115
Injector Plumbing	117
Turbocharger	119
Rocker Lever	121
Engine Coolant Vent	123
Oil Level Sensor	125
Fluid Level Sensor	127
Heat Shield	129
Starting Motor Mounting	131
Paint	133
Starting Motor	135
Exhaust Manifold	137
Torque Converter Oil Cooler	139

Turbocharger Plumbing	141
Valve Cover Arrangement	143
Water Inlet Connection	145
Water Outlet Connection	147
Belt Tensioner	149
Water Pump	151
Water Pump Drive	153
Electronic Control Module Wiring Harness	155
Exhaust Outlet Connection	157

•PARTS NO INDEX

epcatalogs.com

epcatalogs.com

[Buy now](#)

[Cummins Engine QSB4.5 Parts Manual PDF](#)

[With Instant Download](#)