530 Tractor Operators Manual 9-913 Reprinted



This symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED. The message that follows the symbol contains important information about your safety. Carefully read the message. Make sure you fully understand the causes of possible injury or death.

SB001

IF THIS MACHINE IS USED BY AN EMPLOYEE, IS LOANED, OR IS RENTED, MAKE SURE THAT THE OPERATOR UNDERSTANDS THE TWO INSTRUCTIONS BELOW.

BEFORE THE OPERATOR STARTS THE ENGINE:

- 1. GIVE INSTRUCTIONS TO THE OPERATOR ON SAFE AND CORRECT USE OF THE MACHINE.
- 2. MAKE SURE THE C''EL ATOR READS AND UNDERSTANDS THE OPERATOR'S MAN' (1). OR THIS MACHINE.



IMPR PF PPERATION OF THIS MACHINE CAN CAUSE INJURY OR DEATH.

RE STARTING THE ENGINE, DO THE FOLLOWING:

- 1. READ THE OPERATOR'S MANUAL.
- 2. READ ALL SAFETY DECALS ON THE MACHINE.
- 3. CLEAR THE AREA OF OTHER PERSONS.

LEARN AND PRACTICE SAFE USE OF MACHINE CONTROLS IN A SAFE, CLEAR AREA BEFORE YOU OPERATE THIS MACHINE ON A JOB SITE.

It is your responsibility to observe pertinent laws and regulations and to follow manufacturer's instructions on machine operation and maintenance.

See your Authorized Case dealer for additional operator's manuals, parts catalogs, and service manuals.

© 1995 Case Corporation

CASE and IH are registered trade marks of Case Corporation

To the Purchaser of a Case Tractor,

The care you give your new Case Tractor will greatly determine the satisfaction and service life you will obtain from it. Use this manual as your guide. By observing the instructons and suggestions in this manual, your Case Tractor will serve you well for many years.

As an Authorized Case Dealer, we stock Ger hu Case Parts, which are manufactured with the same processor, and skill as the original equipment. Our factory trained staff is kept well informed on the best methods of servicing case equipment and is ready and able to help you.


Should you require additiona 24 or information, contact us.

Your Authorized
CASE DEALER

To insure efficient and prompt service, please furnish us with the Model and Serial Number of your tractor and Serial Number of your engine, in all correspondence or contacts.

TABLE OF CONTENTS

Serial Numbers	8
General Specifications	
Lubrication	
Pressure Fittings	20,21
Fraire Lubrication	22-25
Engine Lubrication	
Transmission Lubrication	
Steering Gear	
Converter Reservoir Oil Level	
Converter Oil Filter	
Hydraulic System	31, 33
Independent P. T. O	
Belt Pulley – Rear Mou tea	
Power Steering	
Operating Instructions	
Pre-Starting C' ock Lost	
Operating Col rol and Instruments	40-45
Run-In Procedure	46
Engine parting, Procedure	47,48
Stopring ar ,ine	48
Collection	49
Du I-R ge Shuttle	53
'pa' ge Drive	54
Operating Case-O-Matic Drive	55-57
ferential Brakes	55
Independent P. T. O.	60
Constant-Running P. T. O.	
Rear Wheel Spacing	64.70
Front Wheel Spacing	71-73
Eagle Hitch and Hydraulic System	
Three-Point Hitch (With Swinging Draft Arms)	
Remote (Portable) Cylinder Attachment	79-80
Drawbar	81
Belt Pulley	82-86
Accessory Tractor Equipment	87-89
Important Checks During Operation	90-91
Service Suggestions	
Fuel Recommendations	100
Preventive Maintenance	
Cooling System	
Fuel and Fuel System	
Governor and Engine Speed	103-113
Valve Adjustment	
Ignition and Electrical Equipment	
Front Wheel Bearings	
Flywheel Clutch	
Adjusting P. T. O. Clutch	
Differential Brakes	······································
Tractor Storage	
Index	
Safety Precautions	Kear Page:



MODEL "541" GENERAL PURPOSE TRACTOR

Buy now

Case 530 Tractor PDF Operator's Manual

With Instant Download