



This symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED. The message that follows the symbol contains important information about your safety. Carefully read the message. Make sure you fully understand the causes of possible injury or death.

SB001

IF THIS MACHINE IS USED BY AN EMPLOYEE, IS LOANED, OR IS RENTED, MAKE SURE THAT THE OPERATOR UNDERSTANDS THE TWO INSTRUCTIONS BELOW.

BEFORE THE OPERATOR STARTS THE ENGINE:

- 1. GIVE INSTRUCTIONS TO THE OPERATOR ON SAFE AND CORRECT USE OF THE MACHINE.
- 2. MAKE SURE THE OPERATOR REALS AND UNDERSTANDS THE OPERATOR'S MANUAL FOR THIS TO UNDERSTANDS THE



IMPROPER OPE TO THIS MACHINE CAN CAUSE INJURY OR DEATH.

BEFORE STAILTING THE ENGINE, DO THE FOLLOWING:

- 1. PEAD (L. OPERATOR'S MANUAL.
- 2. FL 1D ALL SAFETY DECALS ON THE MACHINE.
- EAR THE AREA OF OTHER PERSONS.

LE RN AND PRACTICE SAFE USE OF MACHINE CONTROLS IN A SAFE, LOLEAR AREA BEFORE YOU OPERATE THIS MACHINE ON A JOB SITE.

It is your responsibility to observe pertinent laws and regulations and to follow manufacturer's instructions on machine operation and maintenance.

See your Authorized Case dealer for additional operator's manuals, parts catalogs, and service manuals.

© 1995 Case Corporation

CASE and IH are registered trade marks of Case Corporation

TO THE OWNER

Read this manual before you start the engine or operate your tractor. If you need more information, see your dealer.

Your dealer can give you assistance with CASE CORPORATION approved service parts. Your dealer has technicians with special training that know the best methods of repair and maintenance for your tractor.

Call your dealer if you need any assistance or information.



NOTE: When you are in the tractor seat looking forward, the right hand (RH) and left hand (LH) of the tractor are the same as your right hand and left hand.

PRODUCT IDENTIFICATION AND SERIAL NUMBERS


Write your machine Model Number, Product Identification Number (P.I.N.), and Serial Numbers of major components on the lines provided. If needed, give these numbers to your dealer when you need parts or information for your machine.

- 1. TRACTOR MODEL NUMBER
- 2. PRODUCT IDENTIFICATY N MBER
- 3. ENGINE SERIAL NU'... Si
- 4. ROPS SERIAL NUMBER


IDENTIFICATION NUMBER LOCATIONS

TRACTOF M. DEL NUMBER AND PRODUC, 'DF I. TIFICATION NUMBER PLAT :

ROPS PRODUCT IDENTIFICATION NUMBER PLATE







GENERAL TABLE OF CONTENTS

Safety/Decals······ 4~18
Specifications19~28
Instruments/Controls ······29~45
Operating Instructions46~73
Field Operation74~87
Tires/Wheels/Spacing/Ballas'
Lubrication/Filters/F ids
Maintenance, \distments 134~140
Electr System
Storage 154~155
Detail Index 156~158

Buy now

Case 1120 Tractor PDF Operator Manual

With Instant Download