

ORIGINAL INSTRUCTIONS

epcatalogs.com

I 404
Tractor

OPERATOR'S MANUAL

CNH Industrial (Harbin) Machinery Co. Ltd.
No. 78 Songhua Road, Core District Hanan New Industry Zone,
Harbin City, Heilongjiang Province, P.R. China
+86 4008676600 (for customer in the areas other than Xinjiang Province)/
+86 4000991805 (for customer in Xinjiang Province)

Part number 48096649

Ist edition English
February 2017



epcatalogs.com

SECTION SUMMARY

1 - General Information and Safety

2 - Controls, Instruments and Operation

3 - Field operation

4 - Lubrication and Maintenance

5 - Fault Finding

6 - Accessories

7 - Specifications

8 - First 50 hour Service Forms

9 - Index

NOTES

epcatalogs.com

CONTENTS

Title	Page
Section 1 - General Information and Safety	
To the Owner	1-1
Product Identification	1-3
Ecology and the Environment	1-7
Safety Precautions	1-8
Safety Decals	1-16
International Symbols	1-26
Airborne Noise Emission	1-27
Section 2 - Controls, Instruments and Operation	
Cab	2-6
Seats	2-24
Handbrake, Throttle and Foot Controls	2-30
Instrument Console	2-32
Analogue/Digital Instruments	2-35
Two-speed Powershift Transmission (24 x 24)	2-65
Semi-Powershift Transmission (16 x 16 and 17 x 16)	2-71
Differential Lock and Four Wheel Drive	2-87
Section 3 - Field Operation	
Important Information	3-2
Using Jump Leads (Forster Cables)	3-9
Starting the Engine	3-10
Stopping the Engine	3-15
Turn Assist	3-17
Rear Power Take-Off	3-19
Front Power Take-Off and Hydraulic Lift	3-34
Electronic Hitch Control	3-41
Hydraulic Remote Control Valves	3-53
Load Sensing Remote Control Valves	3-62
Using Remote Hydraulic Equipment	3-74
Three-point Hitch	3-76
Quick Hitch	3-82
Linkage Stabilisers	3-86
Drawbars and Towing Attachments	3-88
Air-Operated Trailer Brakes	3-103
Front Wheel Track Adjustment	3-107
Rear Wheel Track Adjustment	3-115
Ballasting and Tyres	3-120

[Buy now](#)

[Case 1404 Tractor PDF Operators Manual](#)

[With Instant Download](#)