



## MODEL X OWNER'S MANUAL



2018.12  
March 22, 2018




|                                    |     |                                     |     |
|------------------------------------|-----|-------------------------------------|-----|
| Overview.....                      | 2   | Charging.....                       | 150 |
| Interior Overview.....             | 2   | Electric Vehicle Components.....    | 150 |
| Exterior Overview.....             | 3   | Battery Information.....            | 152 |
| Opening and Closing.....           | 4   | Charging Instructions.....          | 154 |
| Doors.....                         | 4   | Maintenance.....                    | 159 |
| Windows.....                       | 12  | Maintenance Schedule.....           | 159 |
| Rear Trunk.....                    | 13  | Tire Care and Maintenance.....      | 160 |
| Front Trunk.....                   | 15  | Cleaning.....                       | 166 |
| Glove Box.....                     | 17  | Wiper Blades and Washer Jets.....   | 169 |
| Cup Holders.....                   | 18  | Fluid Reservoirs.....               | 170 |
| Sun Visors.....                    | 19  | Jacking and Lifting.....            | 172 |
| Seating and Safety Restraints..... | 20  | Parts and Accessories.....          | 173 |
| Front and Rear Seats.....          | 20  | Specifications.....                 | 174 |
| Seat Belts.....                    | 27  | Identification Labels.....          | 174 |
| Child Safety Seats.....            | 30  | Vehicle Loading.....                | 175 |
| Airbags.....                       | 38  | Dimensions and Weights.....         | 178 |
| Driving.....                       | 42  | Subsystems.....                     | 181 |
| Driver Profiles.....               | 42  | Wheels and Tires.....               | 183 |
| Steering Wheel.....                | 44  | Roadside Assistance.....            | 190 |
| Mirrors.....                       | 47  | Contacting Roadside Assistance..... | 190 |
| Starting and Powering Off.....     | 48  | Instructions for Transporters.....  | 191 |
| Gears.....                         | 50  | Consumer Information.....           | 193 |
| Instrument Panel.....              | 51  | Easter Eggs.....                    | 193 |
| Lights.....                        | 57  | About this Owner Information.....   | 194 |
| Wipers and Washers.....            | 61  | Disclaimers.....                    | 195 |
| Brakes.....                        | 62  | Reporting Safety Defects.....       | 197 |
| Traction Control.....              | 64  | Declarations of Conformity.....     | 198 |
| Park Assist.....                   | 65  |                                     |     |
| Vehicle Hold.....                  | 67  |                                     |     |
| Acceleration Modes.....            | 68  |                                     |     |
| Trip Information.....              | 70  |                                     |     |
| Getting Maximum Range.....         | 71  |                                     |     |
| Rear View Camera.....              | 73  |                                     |     |
| Active Spoiler.....                | 74  |                                     |     |
| Towing and Accessories.....        | 75  |                                     |     |
| Driver Assistance.....             | 84  |                                     |     |
| About Driver Assistance.....       | 84  |                                     |     |
| Traffic-Aware Cruise Control.....  | 87  |                                     |     |
| Autosteer.....                     | 93  |                                     |     |
| Auto Lane Change.....              | 96  |                                     |     |
| Autopark.....                      | 98  |                                     |     |
| Lane Assist.....                   | 101 |                                     |     |
| Collision Avoidance Assist.....    | 105 |                                     |     |
| Speed Assist.....                  | 109 |                                     |     |
| Using the Touchscreen.....         | 111 |                                     |     |
| Touchscreen Overview.....          | 111 |                                     |     |
| Controls.....                      | 116 |                                     |     |
| Settings.....                      | 119 |                                     |     |
| Climate Controls.....              | 123 |                                     |     |
| Smart Air Suspension.....          | 129 |                                     |     |
| Media and Audio.....               | 131 |                                     |     |
| Phone.....                         | 136 |                                     |     |
| Maps and Navigation.....           | 138 |                                     |     |
| Calendar.....                      | 143 |                                     |     |
| Security Settings.....             | 144 |                                     |     |
| HomeLink Universal Remote.....     | 145 |                                     |     |
| Connecting to Wi-Fi.....           | 147 |                                     |     |
| Software Updates.....              | 148 |                                     |     |
| Mobile App.....                    | 149 |                                     |     |



1. Interior door handles ([Opening Doors from the Interior](#) on page 7)
2. Traffic-Aware Cruise Control ([Traffic-Aware Cruise Control](#) on page 87) and Autosteer ([Autosteer](#) on page 93)
3. High beams ([High Beam Headlights](#) on page 59), Turn signals ([Turn Signals](#) on page 59), Wipers and washers ([Wipers and Washers](#) on page 61)
4. Steering wheel buttons - left ([Using Left Steering Wheel Buttons](#) on page 44)
5. Instrument panel ([Instrument Panel](#) on page 51)
6. Steering wheel buttons - right ([Using Right Steering Wheel Buttons](#) on page 45)
7. Gear selector ([Shifting Gears](#) on page 50)
8. Touchscreen ([Touchscreen Overview](#) on page 111)
9. Glovebox button ([Glove Box](#) on page 17)
10. Power window switches ([Opening and Closing](#) on page 12)
11. Exterior mirror adjustment switches ([Mirrors](#) on page 17)
12. Seats ([Front and Rear Seats](#) on page 20)
13. Steering column adjuster (hidden from view in the above image) ([Steering Wheel](#) on page 44)
14. Horn ([Horn](#) on page 46)
15. Brakes ([Brakes](#) on page 62)
16. Hazard warning lights ([Hazard Warning Lashers](#) on page 60)
17. Cabin climate control ([Climate Control](#) on page 123)
18. Cup holders ([Cup Holders](#) on page 13)

epcatalogs.com



1. Exterior lights ([Lights](#) on page 57)
2. Front doors ([Opening and Closing Front Doors from Outside Model X](#) on page 7)
3. Falcon wing doors ([Doors](#) on page 4)
4. Charge port ([Charging Instructions](#) on page 15)
5. Active spoiler (optional) ([Active Spoiler](#) on page 74)
6. Driver Assistance cameras ([About Driver Assistance](#) on page 84)
7. Exterior mirrors ([Mirrors](#) on page 47)
8. Radar sensor (hidden from view in this photo image) ([About Driver Assistance](#) on page 84)
9. Hood/Front trunk ([Front Trunk](#) on page 13)
10. Wheels and tires ([Wheels and Tires](#) on page 183)
11. Rear view camera ([Rear View Camera](#) on page 73 and [About Driver Assistance](#) on page 84)
12. Rear trunk/liftgate ([Rear Trunk](#) on page 13)
13. Ultrasonic sensors ([Parking Assist](#) on page 65 and [About Driver Assistance](#) on page 84)



## Keyless Locking and Unlocking

Locking and unlocking Model X is convenient. Although you must be carrying a valid key, there is no need to use it. Model X has sensors around the driver's door that can recognize the presence of a key within a range of approximately three feet (one meter). So, you can keep your key in your pocket or purse and Model X detects it as you approach.

When you walk up to Model X carrying your key, the doors automatically unlock if Passive Entry is on. To open the rear trunk, press the switch located under the trunk's exterior handle.

**Note:** Model X must detect your key near the driver's door before the doors or rear trunk unlock.

**Note:** If Passive Entry is off, you must use the key to unlock Model X. See [Using the Key](#) on page 4.

If equipped with the premium upgrade package, and the **Automatic Doors** setting is turned on, when you walk up to Model X carrying your key, doors automatically unlock and the driver's door partially opens. If not equipped, or if this setting is turned off, doors automatically unlock and a door opens when you press its handle.

**Note:** You can choose whether you want all doors, or just the driver's door, to unlock when you approach Model X carrying your key (see [Door Unlock Mode](#) on page 10).

When carrying your key with you, you can also open the rear trunk without having to use the key. Simply press the switch located under the trunk's exterior handle. Door Unlock Mode (see [Door Unlock Mode](#) on page 10) must be set to **All** and the vehicle must detect the key near the driver's door before opening the rear trunk.


Model X also locks automatically. If you set

**Walk-Away Door Lock** to **ON**, Model X locks when you walk away carrying your key with you (see [Walk-away Locking](#) on page 10).

While sitting inside Model X, you can also lock and unlock the vehicle by touching the icon on the touchscreen's status bar or by using the door controls that are available when you touch **Controls > Doors**.

## Using the Key

To quickly familiarize yourself with the key, think of the key as a miniature version of Model X, with the Tesla badge representing the front. The key has three buttons on the top that feel like softer areas on the surface, and a metal button on each side representing the falcon wing doors.



### 1. Trunk

- Double-click to open the rear trunk.
- If equipped with a powered liftgate, double-click to close the rear trunk. You can also single-click to stop the liftgate when it is moving.
- Hold the button down for one to two seconds to open the charge port door.

### 2. Lock/Unlock All

- Single-click to lock all doors and rear trunk. Hazard warning lights flash on lock.

**Note:** If a door or the rear trunk is open, hazard warning lights flash three times and doors do not lock. To enable a single-click to both close all doors (and rear trunk) and lock them, touch **Controls > Settings > Doors & Locks > Close All with Key Fob > ON**. By default, this setting is **OFF** and when off, you must triple-click this button to close and lock all doors.

[Buy now](#)

[Tesla Model X 12.2018 Noth America Owner's Manual PDF](#)

[With Instant Download](#)