

Tigercat®

X822D/LX822D/X830D/LX830D FELLER BUNCHER

OPERATOR'S MANUAL

SERIAL NUMBER 82263001–82264000

SERIAL NUMBER 82273001–82274000

SERIAL NUMBER 83063001–83064000

SERIAL NUMBER 83073001–83074000



ISSUE 4.2, JUNE 2020

epcatalogs.com

Tigercat X822D/LX822D/X830D/LX830D Feller Buncher

TABLE OF CONTENTS

INTRODUCTION	v
MACHINE IDENTIFICATION AND SERIAL NUMBERS	vi
STANDARDS FOR MACHINE OPERATOR PROTECTIVE STRUCTURE	viii
NON-APPROVED FIELD PRODUCT CHANGES	ix
REGULATORY INFORMATION	x
WARRANTY –EPA	xi
VIBRATION AND NOISE LEVELS	xiii
SAFETY	1
USING HIGH-SPEED DISC SAWS SAFELY	APPENDIX TO SECTION 1
CONTROLS AND OPERATION	2
LUBRICATION AND MAINTENANCE	3

Original Instructions. The information contained in this manual is current at time of printing. Improvements to the machine are ongoing and may not be covered; in these cases, contact your Tigercat dealer for the appropriate information.

X822D/LX822D/X830D/LX830D Available Literature

Operator's Manual (this manual)	Part No. 46198AENG
Service Manual	Part No. 46199AENG
Parts Catalog	Part No. 46200A
Vehicle Moving and Transporting Instructions	Part No. 44821AMUL
Engine Operation and Maintenance Manual, C87 T4f, (822*3001-822*3250 and 830*3001-830*4000)...	Part No. 44554AMUL
Engine Operation and Maintenance Manual, N67 T4f, (822*3251-822*4000)	Part No. 42939AMUL

epcatalogs.com

Tigercat X822D/LX822D/X830D/LX830D Feller Buncher

INTRODUCTION

An Operator's manual, Service manual and a Parts catalog are made available by Tigercat to assist the dealer, customer and operator in becoming familiar with the features of the X822D/LX822D/X830D/LX830D Feller Buncher.

Serial numbers:

X822D 82263001–82264000
LX822D 82273001–82274000
X830D 83063001–83064000
LX830D 83073001–83074000

NOTE: The 4th digit in the machine serial number indicates the machine model type. For example, 6 = Closed Loop Feller Buncher and 7 = Leveling Closed Loop Feller Buncher. For simplicity throughout this manual, the 4th digit has been replaced with an asterisk to indicate that both types of machine models are affected, i.e. 8XX*3001 to 8XX*4000.

The X822D/LX822D/X830D/LX830D Feller Buncher is designed for harvesting trees, selective felling thinning and final felling applications in plantations and natural stands.

The Operator's manual will assist the operator with the techniques of proper and safe operation of the X822D/LX822D/X830D/LX830D Feller Buncher. There is also important information regarding the safe operation of the attachment (if equipped). The Service Manual contains safety and servicing procedures and a preventive maintenance schedule to ensure optimum machine performance.

Section 1 in both the Operator's Manual and the Service Manual contains safety information that must be followed. Throughout the rest of the manuals, DANGER, WARNING and CAUTION notices are displayed where necessary, drawing attention to possible hazards when performing certain procedures.

Only trained personnel should be allowed to operate or work on the machine.

Read and understand the information contained in this manual, and all attachment and accessory manuals associated with this machine, prior to starting, operating, or performing maintenance on the machine for the first time.

Replace the Operator's Manual immediately if lost, damaged, or unreadable.

Follow all jobsite organization rules when operating the machine in coordination with other machines, vehicles, and people on the jobsite.

This manual is an important part of the machine and should remain with the machine if sold.

Tigercat Industries Inc.

P.O. Box 637
Brantford, Ontario
Canada N3T 5P9
Tel: (519) 753-2000
Fax: (519) 753-8272

[Buy now](#)

[Tigercat Feller Buncher X822D, LX822D, X830D, LX830D Operator's Manual PDF](#)

[With Instant Download](#)