

# Tigercat<sup>®</sup>

## 890 LOGGER

# SERVICE MANUAL

SERIAL NUMBER 8900101–8900500



**PRELIMINARY ISSUE 1.1, DECEMBER 2020**

**Tigercat Industries Inc.**

P.O. Box 637  
Brantford, Ontario  
Canada N3T 5P9  
Tel: (519) 753-2000  
Fax: (519) 753-8272

epcatalogs.com

# Tigercat 890 Logger

## TABLE OF CONTENTS

INTRODUCTION .....	v
MACHINE IDENTIFICATION AND SERIAL NUMBERS .....	vi
SAE STANDARDS FOR MACHINE OPERATOR PROTECTIVE STRUCTURES .....	vii
NON-APPROVED FIELD PRODUCT CHANGES .....	viii
REGULATORY INFORMATION .....	ix
EC DECLARATION OF CONFORMITY .....	x
SAFETY .....	1
CONTROLS AND OPERATION .....	2
LUBRICATION AND MAINTENANCE .....	3
HYDRAULIC SYSTEM .....	PRELIMINARY 4
PILOT SYSTEM .....	PRELIMINARY 5
ELECTRICAL AND COMPUTERS .....	PRELIMINARY 6
ENGINE AND ANTI-STALL .....	PRELIMINARY 7
COOLING SYSTEM .....	PRELIMINARY 10
TRACK DRIVE .....	PRELIMINARY 11
BOOM FUNCTIONS .....	PRELIMINARY 12
SWING .....	PRELIMINARY 15
BUTT-N-TOP COVER CLAM GRAPPLE .....	PRELIMINARY 17
CAB TILT AND POWER ROOF .....	PRELIMINARY 23
MISCELLANEOUS .....	PRELIMINARY 25

### CALIFORNIA

#### Proposition 65 Warning

**Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects and other reproductive harm.**

### 890 AVAILABLE LITERATURE

Operator's Manual .....	Part No. 54277AENG
Service Manual (this manual) .....	Part No. 54278AENG
Parts Catalog .....	Part No. 54279A
Vehicle Moving and Transporting Instructions .....	Part No. 56159AMUL
Engine Operation and Maintenance Manual, C87 Tier 2 .....	Part No. 47512AMUL
Engine Operation and Maintenance Manual, C87 Tier 4f .....	Part No. 44554AMUL

epcatalogs.com

# Tigercat 890 Logger

## INTRODUCTION

An Operator's manual, Service manual and a Parts catalog are made available by Tigercat to assist the dealer, customer and operator in becoming familiar with the features of the 890 Logger.

### SERIAL NUMBERS:

890 8900101–8900500

The 890 Logger configured as a Harvester is designed for harvesting trees, at-the-stump processing or roadside processing applications in thinning, selective felling and clear felling applications in plantations and natural stands.

or;

The 890 Logger configured as a Loader is designed for log processing, sorting, log transferring and loading.

or;

The 890 Logger configured as a Shovel Logger is designed for log transferring, loading, and shovel logging (hoe-chucking) by swinging logs closer to the road side minimizing ground surface impact and damage.

The Operator's manual will assist the operator with the techniques of proper and safe operation of the 890 Logger. There is also important information regarding the safe operation of the attachment (if equipped). The service manual contains safety and servicing procedures and a preventive maintenance schedule to ensure optimum machine performance.

Section 1 in both the Operator's manual and the service manual contains safety information that must be followed. As well, throughout the rest of the manuals, DANGER, WARNING and CAUTION notices are displayed where necessary, drawing attention to possible hazards when performing certain procedures.

Only trained personnel are allowed to operate or work on the machine.

The information contained in this manual is current at time of printing. Improvements to the machine are on-going and may not be covered, therefore in these cases contact your Tigercat dealer for the appropriate information.

Tigercat reserves the right to make changes to the machine after this manual release date that may not immediately appear in this manual.

Every effort is made to send out updates on a regular basis. If the machine in question was built after the release date of this manual and there is a discrepancy, call Tigercat service department. The release date appears on the first page.

Tigercat reserves the right to change information contained herein at any time without prior notice.

**Tigercat Industries Inc.**

[Buy now](#)

[Tigercat Logger 890 Service Manual PDF](#)

[With Instant Download](#)