

Instructions for Parts Books

The heading at the top of the page will be the same for the picture of the parts as it is for the page with the part numbers.

Definition of column headings on part number pages:

REF.No → The number referring to the part on the picture page of the parts book.

Part No. → The number assigned to this part at the time of printing the parts book.

Description → Discription of part.

Q'ty → Quantity of part used on that page.

S.No. → Serial number range of the equipment that this part will fit.

>= Your serial number should be greater than or equal to the number shown.

<= Your serial number should be lesser than or equal to the serial number shown.

I/C → Interchangeability of part shown.

↔ The part shown will work for the older and later serial number.

The part shown is not interchangeable with the other serial number.

← new for old

→ old for new


Remarks → Notes about this particular part. Sometimes this may say except [FR] or [CA]

Note about Country Codes:

The parts books we use in the United States of America may also contain information about a part that would be different in another country. It is important that you are aware of the country codes in some instances.

Symbol	Country
A	United States of America
CA	Canada
FR	France
GR	Greece
PO	Portugal
AU	Australia


If the remarks column says for example EXCEPT [FR] this part works in all countries except France. That means it will work here in the USA.



OPTION

ACCESSORIES AND SERVICE PARTS

Item	Part No.	Description	Book
CHASSIS	01A00101	MAIN FRAME [S.No.;A:<=29999]	100A0235
	01A00102	MAIN FRAME [S.No.;4-POSITION C/V:>=30001 to 59999]	100A0235
	01A00103	MAIN FRAME [3-POSITION C/V:S.No.; A:>=60001]	100A0235
FRONT ATTACHMENTS	01A010	BOOM	100A0235
CONTROL VALVE	01B00101	CONTROL VALVE [BX2013 3-POSITION C/V]	100A0235
	01B00102	CONTROL VALVE [3-POSITION C/V]	100A0235
	01B00103	CONTROL VALVE [BX2014 4-POSITION C/V]	100A0235
	01B00104	CONTROL VALVE	100A0235
	01B00501	CONTROL VALVE [COMPONENT PARTS][3-POSITION C/V]	100A0235
	01B00502	CONTROL VALVE [COMPONENT PARTS] [4-POSITION C/V]	100A0235
	01B00503	CONTROL VALVE [COMPONENT PARTS] [4-POSITION C/V]	100A0235
	01B01301	CONTROL LEVER	100A0235
CONTROL LEVER	01B01302	CONTROL LEVER	100A0235
	01B01303	CONTROL LEVER	100A0235
HYDRAULIC SYSTEM	01B01501	CYLINDER/HYDRAULIC HOSE	100A0235
	01B01601	HYDRAULIC HOSE 1 [3-POSITION C/V]	100A0235
	01B01602	HYDRAULIC HOSE 1 [BX2014 4-POSITION C/V]	100A0235
	01B01603	HYDRAULIC HOSE 2	100A0235
	01B01604	HYDRAULIC HOSE [4-POSITION C/V]	100A0235
	01B020	HYDRAULIC TUBE	100A0235
	01B025	CYLINDER (BOOM)[COMPONENT PARTS]	100A0235
	01B030	CYLINDER (BUCKET)[COMPONENT PARTS]	100A0235
OPTION	01B03501	HYDRAULIC BLOCK	100A0235
	01B03502	HYDRAULIC BLOCK	100A0235
	01C001	FRONT GUARD [OPTION]	100A0235
	01D001	ACCESSORIES AND SERVICE PARTS	100A0235
ACCESSORIES / N. SERVICE PARTS			



↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	75538-90190	FRAME MAIN LH(LABEL)	1			ENGLISH	0	0
020	75546-56410	LABEL DANGER 1	1	<=23755		ENGLISH	0	0
020	7J246-56410	LABEL DANGER 1	1	>=23756	←	ENGLISH	0.002	0.0044
030	75599-04630	HEX.BOLT	6			9/16-18UNF*1-1/2	0.067	0.1474
040	75599-33016	WASHER SPRING	6			9/16	0.08	0.176
050	75599-31066	HEX.NUT	3			9/16-18UNF	0.03	0.066
060	75538-90180	FRAME MAIN RH(LABEL)	1			ENGLISH	0	0
070	75546-56450	LABEL CAUTION 1	1	<=23755		ENGLISH	0.001	0.0022
070	7J246-56450	LABEL CAUTION 1	1	>=23756	←	ENGLISH	0.002	0.0044
080	75599-04630	HEX.BOLT	6			9/16-18UNF*1-1/2	0.067	0.1474
090	75599-33016	WASHER SPRING	6			9/16	0.08	0.176
100	75599-31066	HEX.NUT	3			9/16-18UNF	0.03	0.066
110	75538-90130	FRAME SIDE LH(LABEL)	1			ENGLISH	6.7	14.74
120	75567-56420	LABEL DANGER 2	1	<=23755		ENGLISH	0	0
120	7J246-56420	LABEL DANGER 2	1	>=23756	←	ENGLISH	0.001	0.0022
130	75546-56430	LABEL DANGER 3	1	<=23755		ENGLISH NOT SALE	0	0
130	7J246-56430	LABEL DANGER 3	1	>=23756	←	ENGLISH	0.002	0.0044
140	75546-56440	LABEL WARNING 1	1	<=23755		ENGLISH	0.002	0.0044
140	7J246-56442	LABEL WARNING 1	1	>=23756	←	ENGLISH	0.01	0.022
150	99999-99999	BLANK	0				0	0
160	75538-56030	FRAME SIDE RH	1				10.85	23.87
170	75548-56810	PIN	2				0.8	1.76
180	75548-56820	PIN LYNCH	2				0.045	0.099
190	75540-62360	LABEL CONTROL	1				0.001	0.0022
200	75538-95505	KIT FRENCH LA211	1			FRENCH	0.12	0.264
210	75546-99613	LABEL DANGER 1(F)	1			FRENCH	0.001	0.0022
220	75546-99654	LABEL CAUTION(F)	1			FRENCH	0.003	0.0066
230	75567-99622	LABEL DANGER 2(F)	1			FRENCH	0.003	0.0066
240	75546-99613	LABEL DANGER 3(F)	1			FRENCH	0.01	0.022
250	75546-99642	LABEL WARNING 1(F)	2			FRENCH	0.001	0.0022
260	75553-99613	LABEL CONTROL(F)	1			FRENCH	0.001	0.0022

[Buy now](#)

[Kubota LA211 Loader Parts Manual PDF](#)

[With Instant Download](#)