

Instructions for Parts Books

The heading at the top of the page will be the same for the picture of the parts as it is for the page with the part numbers.

Definition of column headings on part number pages:

REF.No → The number referring to the part on the picture page of the parts book.

Part No. → The number assigned to this part at the time of printing the parts book.

Description → Discription of part.

Q'ty → Quantity of part used on that page.

S.No. → Serial number range of the equipment that this part will fit.

>= Your serial number should be greater than or equal to the number shown.

<= Your serial number should be lesser than or equal to the serial number shown.

I/C → Interchangeability of part shown.

↔ The part shown will work for the older and later serial number.

The part shown is not interchangeable with the other serial number.

← new for old

→ old for new

Remarks → Notes about this particular part. Sometimes this may say except [FR] or [CA]

Note about Country Codes:


The parts books we use in the United States of America may also contain information about a part that would be different in another country. It is important that you are aware of the country codes in some instances.

Symbol	Country
A	United States of America
CA	Canada
FR	France
GR	Greece
PO	Portugal
AU	Australia

If the remarks column says for example EXCEPT [FR] this part works in all countries except France. That means it will work here in the USA.

LA351 Loader		Book
Part No.		
01L001	MAIN FRAME	100K0819
01L00202	BOOM	100K0819
01L00301	CONTROL VALVE	100K0819
01L00302	CONTROL VALVE/CONTROL LEVER	100K0819
01L00401	CONTROL VALVE [COMPONENT PARTS]	100K0819
01L00402	CONTROL VALVE [COMPONENT PARTS]	100K0819
01L005	CONTROL LEVER	100K0819
01L006	CYLINDER-HYDRAULIC HOSE	100K0819
01L007	CYLINDER (BOOM) [COMPONENT PARTS]	100K0819
01L008	CYLINDER (BUCKET) [COMPONENT PARTS]	100K0819
01L009	HYDRAULIC TUBE	100K0819
01L010	HYDRAULIC HOSE	100K0819
01L011	FRONT GUARD	100K0819
01L012	ACCESSORIES AND SERVICE PARTS	100K0819

epcatalogs.com






MAIN FRAME

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	75536-90110	FRAME MAIN (LABEL)	1				59	129.8
020	75546-56410	LABEL DANGER 1	1				0	0
030	75546-56450	LABEL CAUTION 1	1				0.001	0.0022
040	01073-51435	HEX BOLT (M14*1.5*35	4				0.063	0.1386
050	75599-33016	WASHER SPRIN GLOCK (	4				0.08	0.176
060	01073-51230	HEX BOLT (M12*1.25*3	4				0.041	0.0902
070	75599-32015	WASHER PLAIN (1/2)	4				0.01	0.022
080	04512-50120	WASHER SPRING LOCK (	4				0	0
090	01050-51235	HEX BOLT (M12*1.75*3	6				0	0
100	04512-50120	WASHER SPRING LOCK (	6				0	0
110	75537-90120	FRAME SIDE LH (LABEL	1				8.5	18.7
120	75546-56430	LABEL DANGER 3	1				0	0
130	75546-56440	LABEL WARNING 1	1				0	0
140	75537-56350	LABEL MODEL	1				0	0
150	75580-56370	LABEL LUBRICATE	1				0.001	0.0022
160	75537-90130	FRAME SIDE RH (LABEL	1				9	19.8
170	75546-56440	LABEL WARNING 1	1				0	0
180	75536-56710	CONNECTOR SIDE FRAME	1				4	8.8
190	75599-04625	HEX BOLT (9/16-18UNF	2				0.056	0.1232
200	75599-31066	HEX NUT (9/16-18UNF)	2				0.03	0.066
210	75599-33016	WASHER SPRING LOCK (	2				0.08	0.176
220	75536-56810	PIN	2				0.74	1.628



[Buy now](#)

[Kubota LA351 Loader Parts Manual PDF](#)

[With Instant Download](#)