

Instructions for Parts Books

The heading at the top of the page will be the same for the picture of the parts as it is for the page with the part numbers.

Definition of column headings on part number pages:

REF.No → The number referring to the part on the picture page of the parts book.

Part No. → The number assigned to this part at the time of printing the parts book.

Description → Discription of part.

Q'ty → Quantity of part used on that page.

S.No. → Serial number range of the equipment that this part will fit.

>= Your serial number should be greater than or equal to the number shown.

<= Your serial number should be lesser than or equal to the serial number shown.

I/C → Interchangeability of part shown.

↔ The part shown will work for the older and later serial number.

The part shown is not interchangeable with the other serial number.

← new for old

→ old for new


Remarks → Notes about this particular part. Sometimes this may say except [FR] or [CA]

Note about Country Codes:

The parts books we use in the United States of America may also contain information about a part that would be different in another country. It is important that you are aware of the country codes in some instances.


Symbol	Country
A	United States of America
CA	Canada
FR	France
GR	Greece
PO	Portugal
AU	Australia

If the remarks column says for example EXCEPT [FR] this part works in all countries except France. That means it will work here in the USA.




ACCESSORIES AND SERVICE PARTS

Item	Part No.	Description	Book
CHASSIS	01A00102	MAIN FRAME	100A0225
	01A00304	BRACE	100A0225
FRONT ATTACHMENTS	01A01003	BOOM	100A0225
CONTROL VALVE	01B00101	CONTROL VALVE	100A0225
	01B00102	CONTROL VALVE	100A0225
	01B00103	CONTROL VALVE	100A0225
	01B00501	CONTROL VALVE [COMPONENT PARTS]	100A0225
	01B00502	CONTROL VALVE [COMPONENT PARTS]	100A0225
	01B00503	CONTROL VALVE [COMPONENT PARTS]	100A0225
CONTROL LEVER	01B01302	CONTROL LEVER	100A0225
	01B01303	CONTROL LEVER	100A0225
HYDRAULIC SYSTEM	01B01502	CYLINDER/HYDRAULIC HOSE	100A0225
	01B016	HYDRAULIC HOSE(HYD.OUTLET BLOCK)	100A0225
	01B02002	HYDRAULIC TUBE	100A0225
	01B02502	CYLINDER (BOOM)[COMPONENT PARTS]	100A0225
	01B03002	CYLINDER (BUCKET)[COMPONENT PARTS]	100A0225
	01B03503	HYDRAULIC BLOCK	100A0225
	01B03504	HYDRAULIC BLOCK	100A0225
ACCESSORIES AND SERVICE PARTS	01D001	ACCESSORIES AND SERVICE PARTS	100A0225



7J043-026-11

OLD PART



7J043-801-10

[Buy now](#)

[Kubota LA402 Loader Parts Manual PDF](#)

[With Instant Download](#)