

Tigercat[®]

850 PROCESSOR

OPERATOR'S MANUAL

SERIAL NUMBER 8500501–8501000



ISSUE 1.0, FEBRUARY 2023

epcatalogs.com

Tigercat 850 Processor

TABLE OF CONTENTS

INTRODUCTION	v
MACHINE IDENTIFICATION AND SERIAL NUMBERS	vi
MACHINE OPERATOR PROTECTIVE STRUCTURES	vii
NON-APPROVED FIELD PRODUCT CHANGES	viii
REGULATORY INFORMATION	ix
WARRANTY –EPA	x
VIBRATION AND NOISE LEVELS	xii
SAFETY	1
CONTROLS AND OPERATION	2
LUBRICATION AND MAINTENANCE	3

Original Instructions. The information contained in this manual is current at time of printing. Improvements to the machine are ongoing and may not be covered; in these cases, contact your Tigercat dealer for the appropriate information.

850 AVAILABLE LITERATURE

Operator's Manual (this manual)	Part No. 70401AENG
Service Manual	Part No. 70402AENG
Parts Catalog	Part No. 57255A
Vehicle Moving and Transporting Instructions	Part No. 70859AMUL
Engine Operation and Maintenance Manual, N67 Tier 2/Non-Certified	Part No. 45045AMUL
Engine Operation and Maintenance Manual, N67 Tier 4f	Part No. 42939AMUL

epcatalogs.com

Tigercat 850 Processor

INTRODUCTION

An Operator's Manual, Service Manual, and a Parts Catalog are made available by Tigercat to assist the dealer, customer and operator in becoming familiar with the features of the 850 Processor.

SERIAL NUMBERS:

850	Processor	8500501–8501000
-----	-----------	-----------------

The 850 Processor is designed for roadside processing.

The Operator's Manual provides the operator with techniques for proper and safe operation of the 850 Processor. There is also important information regarding the safe operation of the attachment (if equipped). The Service Manual contains safety and servicing procedures and a preventive maintenance schedule to ensure optimum machine performance.

Section 1 in both the Operator's Manual and the Service Manual contains safety information that must be followed. Throughout the rest of the manuals, DANGER, WARNING, and CAUTION notices are displayed where necessary, drawing attention to possible hazards when performing certain procedures.

Read and understand the information contained in this manual, and all attachment and accessory manuals associated with this machine, prior to starting, operating, or performing maintenance on the machine for the first time.

This manual uses the International System of Units (SI) and United States customary units. Each measurement is given in SI units first, with the US customary units following in parentheses ().

Replace the Operator's Manual immediately if lost, damaged, or unreadable. This manual is an important part of the machine and should remain with the machine if sold.

Only trained personnel are allowed to operate or work on the machine. Follow all jobsite organization rules when operating the machine in coordination with other machines, vehicles, and people on the jobsite.

Tigercat Industries Inc.

P.O. Box 637
Brantford, Ontario
Canada N3T 5P9
Tel: (519) 753-2000
Fax: (519) 753-8272

[Buy now](#)

[Tigercat Processor 850 Operator's Manual PDF](#)

[With Instant Download](#)