

# Instructions for Parts Books

The heading at the top of the page will be the same for the picture of the parts as it is for the page with the part numbers.

Definition of column headings on part number pages:

**REF.No** → The number referring to the part on the picture page of the parts book.

**Part No.** → The number assigned to this part at the time of printing the parts book.

**Description** → Discription of part.

**Q'ty** → Quantity of part used on that page.

**S.No.** → Serial number range of the equipment that this part will fit.

>= Your serial number should be greater than or equal to the number shown.

<= Your serial number should be lesser than or equal to the serial number shown.

**I/C** → Interchangeability of part shown.

↔ The part shown will work for the older and later serial number.

# The part shown is not interchangeable with the other serial number.

← new for old

→ old for new

**Remarks** → Notes about this particular part. Sometimes this may say except [FR] or [CA]

## Note about Country Codes:


The parts books we use in the United States of America may also contain information about a part that would be different in another country. It is important that you are aware of the country codes in some instances.

| Symbol | Country                  |
|--------|--------------------------|
| A      | United States of America |
| CA     | Canada                   |
| FR     | France                   |
| GR     | Greece                   |
| PO     | Portugal                 |
| AU     | Australia                |

If the remarks column says for example EXCEPT [FR] this part works in all countries except France. That means it will work here in the USA.

HYDRAULIC SYSTEM


FRAME/BOOM



ACCESSORIES

| Item             | Part No. | Description                                | Book     |
|------------------|----------|--------------------------------------------|----------|
| FRAME/BOOM       | 01L01    | SIDE FRAME                                 | 100K0460 |
|                  | 01L02    | BOOM                                       | 100K0460 |
| HYDRAULIC SYSTEM | 01L03    | CONTROL VALVE                              | 100K0460 |
|                  | 01L04    | CONTROL VALVE (NEW TYPE) [COMPONENT PARTS] | 100K0460 |
|                  | 01L05    | LEVER                                      | 100K0460 |
|                  | 01L06    | CONTROL LEVER                              | 100K0460 |
|                  | 01L07    | CONTROL COVER                              | 100K0460 |
|                  | 01L08    | LINK                                       | 100K0460 |
|                  | 01L09    | CYLINDER/HYDRAULIC HOSE                    | 100K0460 |
|                  | 01L10    | CYLINDER (BOOM) LH [COMPONENT PARTS]       | 100K0460 |
|                  | 01L11    | CYLINDER (BOOM) RH [COMPONENT PARTS]       | 100K0460 |
|                  | 01L12    | CYLINDER (BUCKET) LH [COMPONENT PARTS]     | 100K0460 |
|                  | 01L13    | CYLINDER (BUCKET) RH [COMPONENT PARTS]     | 100K0460 |
|                  | 01L14    | HYDRAULIC TUBE                             | 100K0460 |
|                  | 01L15    | DELIVERY/RETURN TUBE                       | 100K0460 |
|                  | 01L16    | ACCESSORIES AND SERVICE PARTS              | 100K0460 |
| ACCESSORIES      |          |                                            |          |

## SIDE FRAME



**SIDE FRAME**

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

| REF.No | Part No.    | Description          | Q'ty | S.No.   | I/C | REMARKS            | Weight (kgf) | Weight (lb) |
|--------|-------------|----------------------|------|---------|-----|--------------------|--------------|-------------|
| 010    | 75580-56010 | FRAME,SIDE LH        | 1    |         |     |                    | 0            | 0           |
| 020    | 75580-56350 | LABEL,MODEL          | 1    |         |     |                    | 0            | 0           |
| 030    | 75540-56360 | LABEL,CAUTION        | 1    |         |     |                    | 0            | 0           |
| 040    | 75580-56030 | FRAME,SIDE RH        | 1    |         |     |                    | 0            | 0           |
| 050    | 75580-56710 | CONNECTOR,SIDE FRAME | 1    |         |     |                    | 0            | 0           |
| 060    | 75599-04635 | HEX.BOLT             | 2    |         |     | (9/16-18UNF*1 3/4) | 0            | 0           |
| 070    | 75599-31066 | HEX.NUT              | 2    |         |     | (9/16-18UNF)       | 0            | 0           |
| 080    | 75599-33016 | WASHER,SPRING LOCK   | 2    |         |     | (9/16)             | 0.08         | 0.176       |
| 090    | 75580-56810 | BOLT,WEDGE           | 2    |         |     |                    | 0            | 0           |
| 100    | 75540-56820 | NUT 1,LOCK           | 2    |         |     |                    | 0            | 0           |
| 110    | 75540-56830 | NUT 2,LOCK           | 2    |         |     |                    | 0            | 0           |
| 120    | 75580-57410 | BRACE LH             | 1    |         |     |                    | 0            | 0           |
| 130    | 75580-57420 | BRACE RH             | 1    |         |     |                    | 0            | 0           |
| 140    | 75540-56720 | PIN,SPRING           | 1    |         |     |                    | 0            | 0           |
| 150    | 75599-04630 | HEX.BOLT             | 1    |         |     | (9/16-18UNF*1 1/2) | 0            | 0           |
| 160    | 75599-31066 | HEX.NUT              | 1    |         |     | (9/16-18UNF)       | 0            | 0           |
| 170    | 75599-33016 | WASHER,SPRING LOCK   | 1    |         |     | (9/16)             | 0.08         | 0.176       |
| 180    | 75580-56370 | LABEL,LUBRICATE      | 1    | >=11215 |     |                    | 0            | 0           |

[Buy now](#)

[Kubota TL420 Loader Parts Manual PDF](#)

[With Instant Download](#)