

Instructions for Parts Books

The heading at the top of the page will be the same for the picture of the parts as it is for the page with the part numbers.

Definition of column headings on part number pages:

REF.No → The number referring to the part on the picture page of the parts book.

Part No. → The number assigned to this part at the time of printing the parts book.

Description → Discription of part.

Q'ty → Quantity of part used on that page.

S.No. → Serial number range of the equipment that this part will fit.

>= Your serial number should be greater than or equal to the number shown.

<= Your serial number should be lesser than or equal to the serial number shown.

I/C → Interchangeability of part shown.

↔ The part shown will work for the older and later serial number.

The part shown is not interchangeable with the other serial number.

← new for old

→ old for new

Remarks → Notes about this particular part. Sometimes this may say except [FR] or [CA]

Note about Country Codes:


The parts books we use in the United States of America may also contain information about a part that would be different in another country. It is important that you are aware of the country codes in some instances.

Symbol	Country
A	United States of America
CA	Canada
FR	France
GR	Greece
PO	Portugal
AU	Australia

If the remarks column says for example EXCEPT [FR] this part works in all countries except France. That means it will work here in the USA.

TL421 Loader Description		Book
Part No.		
01L01	SIDE FRAME	100A0115
01L02	SWING FRAME	100A0115
01L03	BUCKET	100A0115
01L04	CONTROL VALVE	100A0115
01L05	CONTROL VALVE(COMPONENT PARTS)	100A0115
01L07	CONTROL LEVER	100A0115
01L08	LEVER COVER	100A0115
01L09	LINK	100A0115
01L10	CYLINDER HYDRAULIC HOSE	100A0115
01L11	BOOM CYLINDER (COMPONENT PARTS)	100A0115
01L12	BUCKET CYLINDER (COMPONENT PARTS)	100A0115
01L13	HYDRAULIC TUBE	100A0115
01L14	DELIVERY RETURN HOSE	100A0115
01L15	FRONT GUARD	100A0115
01L16	ACCESSORIES AND SERVICE PARTS	100A0115

epcatalogs.com






SIDE FRAME

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	75583-90120	FRAME SIDE LH(LABEL)	1				0	0
020	99999-99999	LABEL MODEL	1			N/A SERVICE	0	0
030	75580-56370	LABEL LUBRICATE	1				0	0
040	75540-56720	PIN SPRING	2				0	0
050	75583-90130	FRAME SIDE RH(LABEL)	1				0	0
060	75599-04630	HEX.BOLT	10			9/16-18UNF*1 1/2	0	0
070	75599-04635	HEX.BOLT	4			9/16-18UNF*1 3/4	0	0
080	75599-31066	HEX.NUT	10			9/16-18UNF	0	0
090	75599-33016	WASHER SPRING LOCK	14			9/16	0.08	0.176
100	75599-32516	WASHER PLAIN	24			9/16HD	0	0
110	75580-56710	CONNECTOR SIDE FRAME	1				0	0
120	75599-04630	HEX.BOLT	2			9/16-18UNF*1 1/2	0	0
130	75599-31066	HEX.NUT	2			9/16-18UNF	0	0
140	75599-33016	WASHER SPRING LOCK	2			9/16	0.08	0.176
150	75546-56412	LABEL DANGER 1	1				0	0
160	75546-56430	LABEL DANGER 3	1				0	0
170	75546-56440	LABEL WARNING 1	2				0	0
180	75546-56450	LABEL CAUTION 1	1				0	0
190	75583-57400	COMP BRACE	2				0	0
200	75599-04630	HEX.BOLT	16			9/16-18UNF*1 1/2	0	0
210	75599-31066	HEX.NUT	16			9/16-18UNF	0	0
220	75599-33016	WASHER SPRING LOCK	16			9/16	0.08	0.176
230	75583-57530	PLATE SPRING	2				0	0
240	75599-01210	HEX.BOLT	4			5/16-18UNC*1/2	0	0
250	75599-33012	WASHER SPRING LOCK	4			5/16	0	0
260	75583-58460	LABEL TL421	2				0	0



[Buy now](#)

[Kubota TL421 Loader Parts Manual PDF](#)

[With Instant Download](#)