

Instructions for Parts Books

The heading at the top of the page will be the same for the picture of the parts at it is for the page with the part numbers.

Definition of column headings on part number pages:

REF.No → The number referring to the part on the picture page of the parts book.

Part No. → The number assigned to this part at the time of printing the parts book.

Part Name → Description of part.

Q'ty → Quantity of part used on that page.

S.No. → Serial number range of the equipment that this part will fit.

>= Your serial number should be greater than or equal to the number shown.

<= Your serial number should be lesser than or equal to the serial number shown.

I/C → Interchangeability of part shown.

= The part shown will work for the older and later serial number.

NI The part shown is not interchangeable with the other serial number.

Remarks → Notes about this particular part. Sometimes this may say except [FR] or [CA]

Note about Country Codes

The parts books we use in the United States of America may also contain information about a part that would be

different in another country. It is important that you are aware of the country codes in some instances.

Symbol Country

A United States of America

CA Canada

FR France


GR Greece

PO Portugal


AU Australia

If the remarks column says for example EXCEPT [FR] this part works in all countries except France. That means it will work here in the USA.

TL500



MAIN FRAME



MAIN FRAME

Ref	Part Number	Part Name	Qty	IC	S/N	Lbs	Remarks
010	7J801-90112	FRAME MAIN(LABEL)	1			0	
020	7J246-56410	LABEL DANGER 1	1			0.004	ENGLISH
030	7J246-56420	LABEL DANGER 2	1			0.002	ENGLISH
040	7J246-56430	LABEL DANGER 3	1			0.004	ENGLISH
050	7J246-56442	LABEL WARNING 1	2			0.022	ENGLISH
060	7J246-56450	LABEL CAUTION 1	1			0.004	ENGLISH
070	7J266-56490	LABEL CAUTION 4	1			0.002	ENGLISH

MAIN FRAME

Ref	Part Number	Part Name	Qty	IC	S/N	Lbs	Remarks
080	75580-56370	LABEL LUBRICATE	1			0.002	ENGLISH
090	7J801-95500	KIT FRENCH(TL500)	1			0	
100	75546-99613	LABEL DANGER 1(F)	1			0.002	FRENCH
110	75546-99632	LABEL DANGER 3(F)	1			0.022	FRENCH
120	75546-99642	LABEL WARNING 1(F)	2			0.002	FRENCH
130	75546-99654	LABEL CAUTION(F)	1			0.006	FRENCH
140	75567-99622	LABEL DANGER 2(F)	1			0.006	FRENCH
150	75580-95550	LABEL LUBRICATE (F)	1			0.002	FRENCH
160	7J266-99682	LABEL CAUTION 4(F)	1			0.002	FRENCH
170	7J266-62360	LABEL CONTROL				0.004	
180	7J801-58460	LABEL TL500	2			0	
190	01176-51435	BOLT	12			0.123	
200	75599-32516	WASHER PLAIN	12			0.024	
210	04512-60140	WASHER SPRING	12			0.017	
220	01128-51245	BOLT	8			0	
230	75599-32515	WASHER PLAIN	8			0.022	
240	32741-29140	SPACER	2			0	
250	32741-29125	CONNECTOR	1			0	
260	01073-51650	BOLT	4			0.231	
270	04512-60160	WASHER SPRING	4			0.022	
280	7K501-16743	PLATE CONNECTING	2			0	
290	01073-51650	BOLT	12			0.231	
300	75599-32517	WASHER PLAIN	24			0.035	
310	04512-60160	WASHER SPRING	12			0.022	
320	02076-50160	NUT	12			0.066	
330	01073-51650	BOLT	6			0.231	

MAIN FRAME

Ref	Part Number	Part Name	Qty	IC	S/N	Lbs	Remarks
340	75599-32517	WASHER PLAIN	6			0.035	
350	04512-60160	WASHER SPRING	6			0.022	
360	34150-37640	PIN SET	4			0.132	
370	32741-29160	STAY FENDER	1			0	
380	01123-60816	BOLT	2			0.022	
390	PN201-82240	CUSHION RUBBER	1			0.165	
400	02156-50080	NUT	2			0.008	
410	04512-60080	WASHER SPRING	2			0.004	

epcatalogs.com

[Buy now](#)

[Kubota TL1150 Loader Parts Manual PDF](#)

[With Instant Download](#)