

Instructions for Parts Books

The heading at the top of the page will be the same for the picture of the parts as it is for the page with the part numbers.

Definition of column headings on part number pages:

REF.No → The number referring to the part on the picture page of the parts book.

Part No. → The number assigned to this part at the time of printing the parts book.

Description → Discription of part.

Q'ty → Quantity of part used on that page.

S.No. → Serial number range of the equipment that this part will fit.

>= Your serial number should be greater than or equal to the number shown.

<= Your serial number should be lesser than or equal to the serial number shown.

I/C → Interchangeability of part shown.

↔ The part shown will work for the older and later serial number.

The part shown is not interchangeable with the other serial number.

← new for old

→ old for new


Remarks → Notes about this particular part. Sometimes this may say except [FR] or [CA]

Note about Country Codes:

The parts books we use in the United States of America may also contain information about a part that would be different in another country. It is important that you are aware of the country codes in some instances.

Symbol	Country
A	United States of America
CA	Canada
FR	France
GR	Greece
PO	Portugal
AU	Australia

If the remarks column says for example EXCEPT [FR] this part works in all countries except France. That means it will work here in the USA.



TOP LINK/TOP LINK BRACKET/PTO PROTECTOR

LABELS

ACCESSORIES AND SERVICE PARTS

OPTION

Item	Part No.	Description	Book
ENGINE	010001	CRANKCASE	100K0780
	010002	OIL PAN	100K0780
	010003	CYLINDER HEAD	100K0780
	010004	GEAR CASE	100K0780
	010005	HEAD COVER	100K0780
	010006	OIL FILTER	100K0780
	010007	DIPSTICK AND GUIDE	100K0780
	010100	MAIN BEARING CASE	100K0780
	010101	CAMSHAFT AND IDLE GEAR SHAFT	100K0780
	010102	PISTON AND CRANKSHAFT	100K0780
	010103	FLYWHEEL	100K0780
	010105	FUEL CAMSHAFT AND GOVERNOR SHAFT	100K0780
	010200	IDLE APPARATUS	100K0780
	010202	INJECTION PUMP	100K0780
	010204	GOVERNOR	100K0780
	01020401	GOVERNOR	100K0780
	010205	SPEED CONTROL PLATE	100K0780
	010206	NOZZLE HOLDER AND GLOW PLUG	100K0780
	010207	NOZZLE HOLDER [COMPONENT PARTS]	100K0780
	010302	FUEL PUMP(MECHANICAL)	100K0780
	010400	WATER FLANGE AND THERMOSTAT	100K0780
	010501	WATER PUMP	100K0780
	010600	VALVE AND ROCKER ARM	100K0780
	010601	INLET MANIFOLD	100K0780
	010602	EXHAUST MANIFOLD	100K0780
	020603	AIR CLEANER	100K0780
	020605	MUFFLER	100K0780
	010900	UPPER GASKET KIT [OPTION]	100K0780
	010901	LOWER GASKET KIT [OPTION]	100K0780
	02A00102	ACCELERATOR LEVER	100K0780
FUEL SYSTEM	02A101	FUEL TANK	100K0780
	02A110	FUEL PIPE	100K0780
	02A130	FUEL FILTER [COMPONENT PARTS]	100K0780
COOLING WATER SYSTEM	02A401	FAN	100K0780
	02A410	WATER PIPE	100K0780
	02A42001	RADIATOR [A] [CA]	100K0780
	02A42002	RADIATOR [EXCEPT [A] [CA]]	100K0780
	02A430	RESERVE TANK	100K0780
ELECTRICAL SYSTEM	02A51001	STOP SOLENOID	100K0780
	01A521	DYNAMO	100K0780
	01A523	DYNAMO [COMPONENT PARTS]	100K0780
	02A525	STARTER	100K0780
	02A530	STARTER [COMPONENT PARTS]	100K0780
	02A535	BATTERY	100K0780
	02B10102	SWITCH	100K0780
	02B11501	PANEL BOARD	100K0780
	02B120	PANEL BOARD [COMPONENT PARTS]	100K0780
	02B301	HEAD RIGHT	100K0780
	02B302	HAZARD LIGHT	100K0780
	02B30401	TAIL LIGHT	100K0780
	02B310	WINKER LAMP	100K0780
	02B50102	ELECTRICAL WIRING	100K0780
	02B50103	ELECTRICAL WIRING [A] [CA]	100K0780
	02B50104	ELECTRICAL WIRING [AU] [NZ]	100K0780

Item	Part No.	Description	Book
CLUTCH	01C101	CLUTCH	100K0780
	02C110	CLUTCH ROD	100K0780
	02C301	CLUTCH PEDAL	100K0780
	02C401	CLUTCH HOUSING	100K0780
	02C41502	CENTER FRAME	100K0780
TRANSMISSION	02C42002	TRANSMISSION CASE	100K0780
	02C425	DIFFERENTIAL GEAR CASE	100K0780
	02C427	REAR AXLE CASE	100K0780
	02D001	CLUTCH SHAFT	100K0780
	02D00502	PROPELLER SHAFT	100K0780
	02D010	HST	100K0780
	02D01501	HST [COMPONENT PARTS]	100K0780
	02D01502	HST [COMPONENT PARTS]	100K0780
	02D01503	HST [COMPONENT PARTS]	100K0780
	02D10302	FRONT SHAFT	100K0780
	02D13502	PTO SHAFT	100K0780
	02D13702	MID PTO	100K0780
	02D140	REAR DIFFERENTIAL	100K0780
	02D14002	FRONT WHEEL PROPELLER SHAFT	100K0780
	02D15002	2ND SHAFT	100K0780
	02D15202	3RD SHAFT	100K0780
	02D15302	4TH SHAFT	100K0780
	02D21702	RANGE GEAR SHIFT FORK	100K0780
	02D22002	PTO GEAR SHIFT FORK	100K0780
SPEED CHANGE	02D225	DIFFERENTIAL LOCK SHIFT FORK	100K0780
	02D30101	REAR AXLE	100K0780
	02E00102	BRAKE	100K0780
REAR AXLE BRAKE	02E00502	BRAKE ROD	100K0780
	02E01503	PARKING BRAKE LEVER [EXCEPT [AU] [NZ]]	100K0780
	02E01504	PARKING BRAKE LEVER [AU] [NZ]	100K0780
SPEED CHANGE	02F030	SPEED SET LEVER	100K0780
	02F107	NEUTRAL HOLDER LINK	100K0780
	02F108	SPEED CONTROL PEDAL	100K0780
	02F11001	RANGE GEAR SHIFT LEVER	100K0780
	02F113	FRONT WHEEL DRIVE LEVER	100K0780
	02F12501	PTO GEAR SHIFT LEVER	100K0780
	02F14301	HYDRAULIC CONTROL LEVER	100K0780
PUMP/MOTOR SYSTEM BRAKE REAR AXLE FRONT AXLE	02F20101	BRAKE PEDAL	100K0780
	02F20502	DIFFERENTIAL LOCK PEDAL	100K0780
	02G10102	FRONT AXLE FRAME	100K0780
	02G10501	FRONT AXLE CASE	100K0780
	02G11501	FRONT DIFFERENTIAL	100K0780
	02G120	DIFFERENTIAL GEAR SHAFT	100K0780
	02G123	BEVEL GEAR CASE	100K0780
	02G125	FRONT AXLE CASE	100K0780
	02G130	FRONT AXLE	100K0780
	02G13502	FRONT DRIVE SHAFT	100K0780
STEERING	02H00101	KNUCKLE ARM	100K0780
	02H003	DRAG LINK	100K0780
	02H00501	TIE ROD	100K0780
	02H101	STEERING HANDLE	100K0780
	02H105	STEERING POST	100K0780
	02J101	HYDRAULIC PUMP(PS)	100K0780
	02J105	HYDRAULIC PUMP(PS) [COMPONENT PARTS]	100K0780
	01J120	HYDRAULIC PUMP	100K0780
	01J125	HYDRAULIC PUMP [COMPONENT PARTS]	100K0780

Item	Part No.	Description	Book
PUMP/MOTOR SYSTEM	02J201	HYDRAULIC OIL LINE(SUCTION)	100K0780
	02J21001	HYDRAULIC OIL LINE(DELIVERY)	100K0780
	02J215	HYDRAULIC OIL LINE(STEERING)	100K0780
	02J235	HYDRAULIC OIL LINE(HST)	100K0780
	02J240	HYDRAULIC OIL LINE(OIL COOLER)	100K0780
	02J24502	HYDRAULIC OIL LINE(F/M)	100K0780
	02J30101	HYDRAULIC CYLINDER	100K0780
	02J31001	HYDRAULIC PISTON/LIFT ARM	100K0780
	02J33001	FEED BACK LEVER	100K0780
	02J40501	CONTROL VALVE	100K0780
	02J41001	CONTROL VALVE [COMPONENT PARTS]	100K0780
TOP LINK/TOP LINK BRACKET/PTO PROTECTOR	02K10101	3-POINT LINKAGE 2(LIFT ROD)	100K0780
	02K11501	LOWER LINK	100K0780
	02K12001	3-POINT LINKAGE 1(TOP LINK)	100K0780
	02K125	CHECK CHAIN	100K0780
	02L105	DRAWBAR	100K0780
	02L116	REAR HITCH	100K0780
	02L12501	PTO PROTECTOR [A] [CA]	100K0780
HOOD/BONNET	02L12502	PTO PROTECTOR [AU] [NZ]	100K0780
	02M101	FRONT GRILLE [A] [CA]	100K0780
	02M10101	FRONT GRILLE [AU] [NZ]	100K0780
	02M105	BONNET	100K0780
	02M11301	PANEL COVER	100K0780
	02M120	SIDE COVER	100K0780
	02M13001	SHUTTER PLATE [A] [CA]	100K0780
	02M13002	SHUTTER PLATE [AU] [NZ]	100K0780
	02M20702	LEVER GUIDE	100K0780
	02M21001	FENDER [A] [CA]	100K0780
	02M21002	FENDER [AU] [NZ]	100K0780
FRONT TIRE	02M21201	FENDER STAY	100K0780
	02M215	FLOOR SEAT	100K0780
	02M21701	SEAT SUPPORT	100K0780
	02M225	STEP	100K0780
	02M30101	ROPS(RIGID TYPE) [EXCEPT [AU]]	100K0780
	02M30102	ROPS(FOLDABLE TYPE)	100K0780
	02M30103	ROPS [AU]	100K0780
	02M501	SMV EMBLEM	100K0780
	02R10101	FRONT WHEEL(6-12) [A] [CA] [B7510DN [OPTION]]	100K0780
	02R10102	FRONT WHEEL(23*8.50-12) [A] [CA]	100K0780
	02R10103	FRONT WHEEL(21*8.00-10) [A] [CA]	100K0780
REAR TIRE	02R10104	FRONT WHEEL(23*8.50-12) [A] [CA]	100K0780
	02R10105	FRONT WHEEL(6-12) [EXCEPT [A] [CA]]	100K0780
	02R10106	FRONT WHEEL(22*8.50-12) [EXCEPT [A] [CA]]	100K0780
	02R11001	REAR WHEEL(9.5-16) [A] [CA]	100K0780
	02R11002	REAR WHEEL(33*12.5-15) [A] [CA]	100K0780
	02R11003	REAR WHEEL(31*15.5-15) [A] [CA]	100K0780
	02R11004	REAR WHEEL(12-16.5) [A] [CA]	100K0780
	02R11005	REAR WHEEL(9.5-16) [EXCEPT [A] [CA]]	100K0780
	02R11006	REAR WHEEL(31*13.5-15) [EXCEPT [A] [CA]]	100K0780
LABELS	02S10105	LABEL [A] [CA] [ENGLISH]	100K0780
	02S10106	LABEL [A] [CA] [FRENCH]	100K0780
	02S10107	LABEL [AU]	100K0780
	02S10108	LABEL [NZ]	100K0780

[Buy now](#)

[Kubota B7510HSD Tractor Parts Manual PDF](#)

[With Instant Download](#)