

Instructions for Parts Books

The heading at the top of the page will be the same for the picture of the parts as it is for the page with the part numbers.

Definition of column headings on part number pages:

REF.No → The number referring to the part on the picture page of the parts book.

Part No. → The number assigned to this part at the time of printing the parts book.

Description → Discription of part.

Q'ty → Quantity of part used on that page.

S.No. → Serial number range of the equipment that this part will fit.

>= Your serial number should be greater than or equal to the number shown.

<= Your serial number should be lesser than or equal to the serial number shown.

I/C → Interchangeability of part shown.

↔ The part shown will work for the older and later serial number.

The part shown is not interchangeable with the other serial number.

← new for old

→ old for new

Remarks → Notes about this particular part. Sometimes this may say except [FR] or [CA]


Note about Country Codes:

The parts books we use in the United States of America may also contain information about a part that would be different in another country. It is important that you are aware of the country codes in some instances.

Symbol	Country
A	United States of America
CA	Canada
FR	France
GR	Greece
PO	Portugal
AU	Australia

If the remarks column says for example EXCEPT [FR] this part works in all countries except France. That means it will work here in the USA.

ALL PRODUCT INDEX
L2350DT



Item	Part No.	Description	Book
ENGINE	01T001	CRANKCASE	100K0383
	01T002	OIL PAN	100K0383
	01T003	PISTON AND CRANKSHAFT	100K0383
	01T004	MAIN BEARING CASE	100K0383
	01T005	FLYWHEEL	100K0383
	01T006	CYLINDER HEAD	100K0383
	01T007	VALVE AND ROCKER ARM	100K0383
	01T008	NOZZLE HOLDER AND GLOW PLUG	100K0383
	01T009	NOZZLE HOLDER [COMPONENT PARTS]	100K0383
	01T010	CYLINDER HEAD COVER	100K0383
	01T011	INLET MANIFOLD	100K0383
	01T016	CAMSHAFT	100K0383
	01T017	GEAR CASE	100K0383
	01T018	WATER PUMP	100K0383
	01T019	WATER FLANGE AND THERMOSTAT	100K0383
	01T020	INJECTION PUMP AND FUEL CAMSHAFT	100K0383
	01T021	INJECTION PUMP [COMPONENT PARTS]	100K0383
	01T022	SPEED CONTROL PLATE	100K0383
	01T023	GOVERNOR	100K0383
	01T024	UPPER GASKET KIT	100K0383
	01T025	LOWER GASKET KIT	100K0383
	02T012	AIR CLEANER	100K0383
	02T013	AIR CLEANER [COMPONENT PARTS]	100K0383
	02T014	EXHAUST MANIFOLD	100K0383
	02T01501	MUFFLER	100K0383
	02T01502	UNDER MUFFLER [OLD TYPE] [OPTION]	100K0383
	02T01503	UNDER MUFFLER [NEW TYPE] [OPTION]	100K0383
	02T026	HAND ACCELERATOR LEVER	100K0383
FUEL SYSTEM	02T02702	FUEL TANK	100K0383
COOLING WATER SYSTEM	02T028	FUEL FILTER AND FUEL PIPE	100K0383
	02T029	WATER PIPE	100K0383
	02T030	RADIATOR	100K0383
ELECTRICAL SYSTEM	02T031	SHUTTER	100K0383
	02T032	DYNAMO AND FAN	100K0383
	02T033	DYNAMO [COMPONENT PARTS]	100K0383
	02T034	STARTER	100K0383
	02T035	STARTER [COMPONENT PARTS]	100K0383
	02T036	BATTERY	100K0383
	02T037	SWITCH	100K0383
	02T03801	LIGHT [OIL TYPE]	100K0383
	02T03802	LIGHT [NEW TYPE]	100K0383
	02T03902	REGULATOR AND METER	100K0383
	02T04003	ELECTRICAL WIRING [OLD TYPE]	100K0383

Item	Part No.	Description	Book
ELECTRICAL SYSTEM	02T04004	ELECTRICAL WIRING [NEW TYPE]	100K0383
CLUTCH	02T041	CLUTCH	100K0383
	02T042	CLUTCH LEVER	100K0383
	02T043	CLUTCH PEDAL	100K0383
	02T044	CLUTCH HOUSING	100K0383
TRANSMISSION	02T045	TRANSMISSION CASE	100K0383
	02T046	MAIN SHAFT	100K0383
	02T047	COUNTERSHAFT	100K0383
	02T04802	PTO COUNTERSHAFT	100K0383
	02T049	REVERSE SHAFT	100K0383
SPEED CHANGE LEVER	02T050	MAIN GEAR SHIFT LEVER	100K0383
	02T051	PTO GEAR SHIFT LEVER	100K0383
	02T052	MAIN GEAR SHIFT FORK	100K0383
	02T053	PTO GEAR SHIFT FORK	100K0383
	02T054	PTO GEAR SHIFT FORK AND LEVER	100K0383
REAR AXLE AND REAR WHEEL	02T055	SPIRAL BEVEL PINION	100K0383
	02T056	REAR DIFFERENTIAL	100K0383
	02T057	DIFFERENTIAL LOCK PEDAL	100K0383
	02T058	REAR AXLE	100K0383
	02T05901	REAR WHEEL (9.5-24)	100K0383
	02T05902	REAR WHEEL (11.2-24)	100K0383
	02T05903	REAR WHEEL (13.6-16)	100K0383
	02T05904	REAR WHEEL (13.6-16)	100K0383
	02T05905	REAR WHEEL (355/80-D20)	100K0383
BRAKE	02T06002	BRAKE	100K0383
	02T061	BRAKE PEDAL	100K0383
	02T062	PARKING BRAKE LEVER	100K0383
FRONT AXLE AND FRONT WHEEL AND CHASSIS	02T067	FRONT AXLE	100K0383
	02T068	FRONT AXLE CASE	100K0383
	02T069	DIFFERENTIAL GEAR SHAFT	100K0383
	02T070	FRONT DIFFERENTIAL CASE	100K0383
	02T071	FRONT DIFFERENTIAL	100K0383
	02T072	PROPELLER SHAFT	100K0383
	02T073	FRONT WHEEL DRIVE CASE	100K0383
	02T074	FRONT WHEEL DRIVE LEVER	100K0383
	02T07501	FRONT WHEEL (6-14)	100K0383
	02T07502	FRONT WHEEL (7-16)	100K0383
	02T07503	FRONT WHEEL (24X8.50-14)	100K0383
	02T076	FRONT AXLE FRAME	100K0383
STEERING	02T07901	STEERING LINKAGE (DRAG LINK)(MS)	100K0383
	02T07902	STEERING LINKAGE (DRAG LINK)(PS)	100K0383
	02T080	STEERING LINKAGE (TIE ROD)	100K0383
	02T08101	MANUAL STEERING AND HANDLE (MS)	100K0383
	02T08102	POWER STEERING AND HANDLE	100K0383
	02T08201	MANUAL STEERING [COMPONENT PARTS]	100K0383
	02T08202	POWER STEERING [COMPONENT PARTS]	100K0383

Item	Part No.	Description	Book
HYDRAULIC SYSTEM	02T08302	HYDRAULIC PUMP	100K0383
	02T08402	HYDRAULIC PUMP [COMPONENT PARTS]	100K0383
	02T08502	HYDRAULIC OIL LINE	100K0383
	02T086	FLOW PRIORITY VALVE (PS)	100K0383
	02T087	CONTROL VALVE	100K0383
	02T08801	CONTROL VALVE (POSITION) [A] [CA] [COMPONENT PARTS]	100K0383
	02T08802	CONTROL VALVE (POSITION) [AU] [COMPONENT PARTS]	100K0383
	02T08803	CONTROL VALVE [OPTION] [COMPONENT PARTS]	100K0383
	02T089	DRAFT CONTROL VALVE [OPTION]	100K0383
	02T090	DRAFT CONTROL VALVE [OPTION] [COMPONENT PARTS]	100K0383
	02T091	HYDRAULIC CYLINDER	100K0383
	02T092	CYLINDER FRONT COVER	100K0383
	02T093	LIFT ARM	100K0383
	02T094	FEED BACK LEVER	100K0383
	02T09501	POSITION CONTROL LEVER [OLD TYPE]	100K0383
	02T09502	POSITION CONTROL LEVER [NEW TYPE]	100K0383
	02T09601	3-POINT LINKAGE 1 (LOWER LINK AND TOP LINK) [A] [CA]	100K0383
	02T09602	3-POINT LINKAGE 1 (LOWER LINK AND TOP LINK) [AU]	100K0383
	02T097	3-POINT LINKAGE 2 (LIFT ROD)	100K0383
	02T098	TOP LINK BRACKET AND LOWER LINK HOLDER	100K0383
	02T099	TOP LINK BRACKET (WITH DRAFT CONTROL) [OPTION]	100K0383
HITCH AND DRAWBAR	02T100	DRAWBAR AND HITCH	100K0383
HOOD(BONNET) AND ROPS	02T101	PTO SHAFT PROTECTOR	100K0383
	02T102	FRONT GRILLE	100K0383
	02T103	HOOD (BONNET)	100K0383
	02T104	HOOD (SIDE COVER)	100K0383
	02T10501	FENDER [OLD TYPE]	100K0383
	02T10502	FENDER [NEW TYPE]	100K0383
	02T106	SEAT	100K0383
	02T10701	STEP [OIL TYPE]	100K0383
	02T10702	STEP [NEW TYPE]	100K0383
	02T108	FENDER SUPPORT [NEW TYPE]	100K0383
LABELS	02T10901	ROPS [OLD TYPE]	100K0383
	02T10902	ROPS [NEW TYPE]	100K0383
	02T11001	LABEL 1 [OLD TYPE]	100K0383
	02T11002	LABEL 1 [NEW TYPE]	100K0383

[Buy now](#)

[Kubota L2350DT Tractor Parts Manual PDF](#)

[With Instant Download](#)