


**TCM トムファイター**  
**TOMFIGHTER**

**Book No.609B**

**PARTS**  
**MANUAL** **MODEL 808**



**TCM 東洋運搬機株式会社**

[epcatalogs.com](http://epcatalogs.com)




# ご使用のまえに

このパーツマニュアルは、TCM **HL717** の車両本体の構成部品を収録しています。

## 部品ご注文について


部品ご注文の際は、必ず車両の形式・製造番号（号車）、部品番号および注文数を明示してください。

製造番号（号車）は、つぎの車両銘板に表示しています。



部品は必ず「**TCM純正部品**」をご使用ください。純正部品以外の部品をご使用になり、故障が発生した場合は保証できません。

## ご使用について



### 略語および記号

- ASS'Y** 組立品を示します。
- R・H** 車両の前方向に向かって右側を示します。
- L・H** 車両の前方向に向かって左側を示します。
- A** 必要に応じた数を使用します。
- S** 単体販売しません。
- Z** 歯数を示します。


部品は品質向上のため、予告なく変更することがありますので、あらかじめご了承ください。詳細は **TCM** 指定整備工場にご相談ください。

# INTRODUCTION

This Parts Manual contains the component parts of the truck main body of **TCM TOMFIGHTER**.


## How to order parts

When ordering parts, specify the model name of your machine, its serial number (machine number), and the part number and quantity required of each part. The machine serial number is shown in the following name plate.



Always use "TCM's Genuine Parts". We cannot guarantee any loss or trouble attributable to other parts than ours.

## How to use the manual



### Abbreviations and symbols

- ASS'Y ..... Designates an assembly.
- R.H ..... The right-hand side as looking in the front direction of the truck.
- L.H ..... The left-hand side as looking in the front direction of the truck.
- A R ..... "As required." Designating the quantity required specifically.
- § ..... Not sold separately.
- Z ..... Designates the number of teeth of a gear.

Materials and specifications subject to change without notice.



[Buy now](#)

[TCM Tomfighter 808 Parts Manual PDF](#)

[With Instant Download](#)