

## Main Unit Section

### Changes from Model 3

Overall Specifications .....	1
1. Specifications Comparison Table .....	1
2. Performance Improvements .....	2
Hydraulic-related Changes .....	3
1. Use of High-performance Return Filter (nephron filter and breaker filter eliminated) .....	3
2. Use of Add-on Valve.....	5
3. Multi Purpose Circuit Switched to One-touch Operation (breaker ⇄ crusher) .....	6
Hydraulic Pump .....	7
1. Hydraulic Pump Changes.....	7
2. Appearance Changes.....	7
3. Circuit Changes.....	7
4. Reduced Flow Force .....	8
5. Straight Travel Valve .....	9
6. Heat Circuit.....	10
Lower-section Related Changes.....	12
1. Center Joint Installation Section Notch Dimensions.....	12
2. Grease Rail Seal .....	12
3. Center Joint Rotation Stopper Installation Surface.....	12
4. Track Roller .....	13
5. Carrier Roller .....	14
6. Track Guard .....	14
Cab-related Changes .....	15
1. Cab Shape .....	15
2. Irregularly Shaped Steel Pipe Structure .....	15
3. Beefed Up Equipment .....	16
4. Interior Equipment .....	17
5. Front Window Lock Mechanism.....	20
Upper Swing Body Changes .....	21
1. High-rigidity Platform .....	21

# Content

---

Attachment Changes .....	22
1. Boom .....	22
2. Arm .....	23
3. Coupler Pin Fastening .....	24
4. Pipe Clamp .....	24
5. Bucket Edge Bushing .....	24
6. Use of Plastic Shims .....	24
7. Reduced Boom Foot Section Play .....	24
Specifications	
Overall .....	25
1. Main Data .....	25
2. Performance .....	25
3. Main Body Dimensions .....	25
4. Engine .....	26
5. Cooling System .....	26
6. Upper Side Work System .....	27
7. Operating Device .....	27
8. Swing Units .....	28
9. Travel Lower Body .....	29
Hydraulic Equipment .....	29
1. Hydraulic Device .....	29
2. Control Valve, Cylinder .....	30
Capacities, Filters .....	30
1. Water and Oil Capacities .....	30
2. Hydraulic Oil Filters .....	30
3. Fuel Filter .....	30
Lifting Capacity	
Precautions for lifting loads with the hydraulic excavator .....	31
Lifting Capacities (Standard Arm) .....	32
Lifting Capacities (Short Arm) .....	33
Lifting Capacities (Long Arm) .....	34
Overall View	
Overall View .....	35
1. Standard Arm (3.18 m) .....	35
2. Short Arm (2.65 m) .....	35
3. Long Arm (3.66 m) .....	36

## Work Range Diagram

Work Range Diagram .....	37
1. Standard Arm (3.18 m).....	37
2. Short Arm (2.65 m).....	38
3. Long Arm (3.66 m) .....	39

CONFIDENTIAL: FOR THE INTERNAL  
USE OF TSM GLOBAL  
*epccatalogs.com*

## Summary Section

### Main Equipment Table

Lower Component .....	1
1. Travel Unit.....	1
2. Take-up Roller .....	1
3. Upper-roller .....	1
4. Lower-roller.....	1
5. Recoil Spring .....	2
6. Shoes .....	2
Upper Component .....	3
1. Swing Unit .....	3
Engine-related .....	4
1. Engine .....	4
2. Muffler .....	5
3. Air Cleaner (double element).....	5
4. Pre Cleaner (option) .....	5
5. Radiator.....	5
Hydraulic Device .....	6
1. Hydraulic Pump .....	6
2. Add on Pump (option) .....	6
3. Pump F - Diagram .....	7
Control-related.....	8
1. Control Valve .....	8
2. Remote Control Valve (left / right, travel operations) .....	9
3. Remote Control Valve Characteristic Diagram .....	10
4. Cushion Valve (heat circuit, with shuttle valve).....	12
5. Center joint .....	12
6. Solenoid Valve (5-stack).....	12
Backhoe Attachment.....	13
1. Cylinder .....	13
2. Cylinder with HBCV (option) .....	14
Equipment Layout Diagram .....	
Main Equipment Layout .....	15
Consumable Part Layout .....	16
Standard Machine Option List .....	
List of Optional Components .....	17

## Hydraulic Section

### Hydraulic Equipment Layout

Overall View.....	1
Pump Chamber Hydraulic Equipment Layout.....	2
Swing Body Center Section Hydraulic Equipment Layout .....	3
Housing Left Side Hydraulic Equipment Layout .....	4
Layout of Hydraulic Equipment in Cab .....	5

### Port Diagram

Pump .....	6
------------	---

1. Hydraulic Pump (standard model) .....	6
--	---

Valves .....	7
--------------	---

1. Control Valve .....	7
------------------------	---

2. 5-stack Solenoid Valve .....	10
---------------------------------	----

3. 2-stack Solenoid Valve .....	11
---------------------------------	----

4. Remote Control Valves (upper, travel) .....	12
--	----

5. Cushion Valve.....	14
-----------------------	----

6. 3-Direction Valve/Shut-off Valve (Option) .....	15
--	----

7. HBCV (Option) .....	16
------------------------	----

Manifolds .....	17
-----------------	----

1. Manifold inside Cab.....	17
-----------------------------	----

2. Manifold (accumulator section).....	17
--	----

3. Manifold (hydraulic oil tank section).....	18
---	----

Motors.....	19
-------------	----

1. Swing Motor .....	19
----------------------	----

2. Travel Motor .....	20
-----------------------	----

3. Center Joint .....	21
-----------------------	----

### Pilot Hose Connection Diagram

Pilot P and T Lines .....	22
---------------------------	----

Pilot Control Line .....	25
--------------------------	----

Pilot Control Line (HBCV).....	28
--------------------------------	----

### Function List

Function Table .....	30
----------------------	----

Explanation of New Functions .....	32
------------------------------------	----

1. Swing Relief Cut Control .....	32
-----------------------------------	----

2. Negative Control Power Save Control .....	34
--	----

3. Option Line Flow Adjustment Control .....	35
--	----

4. Multi Purpose Circuit (breaker ⇔ crusher) One-touch Switching Control .....	36
--	----

5. Bucket-close Regenerative Circuit.....	37
---	----

[Buy now](#)

[Sumitomo Hydraulic Excavator SH300-5 Service Manual PDF](#)

[With Instant Download](#)