

@Hitachi Construction Machinery Co., Ltd.

URL:http://www.hitachi-c-m.com

Introduction

This Manual describes the structure and the troubleshooting of electronic control fuel injection system (common rail type) in 4HK1 and 6HK1 industrial engines.

Use this manual sufficiently to perform service work properly and quickly.

Pil construction Machinery Co., Ltd

General Contents

Control System

Engine Control

(Electronic control fuel injection system (Common rail type))

Engine Manual (2/2)

Disassemble and Assemble Engine

General Information

Engine Mechanical (4HK1、6HK1)

Cooling System

Fuel System

Engine Electrical

Exhaust System and Turbocharger

Buy now
Hitachi 4HK1, 6HK1 Engine Manual PDF
With Instant Download