




BACKHOE

SERVICE MANUAL



MELROE  
INGERSOLL-RAND

6900622(6-98)

  
**bobcat**  
© Melroe Company 1997  
Printed in U.S.A.

epcatalogs.com

# MAINTENANCE SAFETY



## WARNING


Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manual, Operator's Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.

W-2003-0903



**Safety Alert Symbol:** This symbol with a warning statement, means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.

### CORRECT



B-10731a

### WRONG



B-05898

- ⚠ Never service the Bobcat Loader or backhoe without instructions. See Operation & Maintenance and Service Manual.
- ⚠ Check engine and hydraulic fluid daily.
- ⚠ Cleaning and maintenance are required daily.
- ⚠ Never service or adjust loader/backhoe with the engine running unless instructed to do so in manual.

- ⚠ Safety glasses are needed for eye protection from electrical arcs, battery acid, compresses springs, fluids under pressure and flying debris or when tools are used. Use eye protection approved for type of welding.

- ⚠ Always lower the backhoe attachment to the ground before lubricating or servicing.
- ⚠ Avoid contact with leaking hydraulic fluid or diesel fuel under pressure. It can penetrate skin or eyes.
- ⚠ Stop, cool and clean engine of flammable materials before checking fluids.
- ⚠ Keep body, loose objects are clothing away from moving parts, electrical contacts, hot parts and

MSW31-0805



	905B	923SA	923S	928S	907	908B	909	911	730S	725S	835S	607	709	811	8709	911B	911C	913	914	914B
440																				
450																				
453																				
543																				
553																				
630																				
645																				
643																				
730																				
743																				
751																				
753																				
753H																				
753L																				
763																				
7753																				
773																				
843																				
853																				
853H																				
863																				
873																				
943																				
953																				
963																				
2400																				

epcatatogs.com

NOTE: Refer to the sales handbook for Backhoe mounting kit part numbers and serial numbers.

[Buy now](#)

[Bobcat Backhoe 406, 506, 607, 709, 709FDS, 8811, MO6 Service Manual PDF](#)

[With Instant Download](#)