

1000/2000

OPERATOR'S MANUAL

epcatalogs.com

PUPIL TRANSPORT/SHUTTLE SERIES

DECEMBER 2010

Operator's Manual

2010 DECEMBER
OM3758EN

Allison Transmission

2010 Uprate
VOCATIONAL MODELS

Pupil Transport/Shuttle Series (PTS)

1000 and 2000 Product Families

4th Generation Controls with Prognostics

1000 PTS	2200 PTS	2500 PTS
2100 PTS	2350 PTS	2550 PTS

 **Allison**
Transmission
Allison Transmission, Inc.
P.O. Box 894 Indianapolis, Indiana 46206-0894
www.allisontransmission.com

Printed in USA

Copyright © 2010 Allison Transmission, Inc.

NOTES

epcatalogs.com

TABLE OF CONTENTS

TRADEMARK USAGE	6
IMPORTANT SAFETY INFORMATION	7
LIST OF WARNINGS	8

1.0 INTRODUCTION

1.1 KEEPING THAT ALLISON ADVANTAGE	23
1.2 A BRIEF DESCRIPTION OF THE ALLISON 1000 AND 2000 PRODUCT FAMILIES TRANSMISSIONS	28
1.3 ELECTRONIC CONTROL SYSTEM	28
1.4 TORQUE CONVERTER	29
1.5 PLANETARY GEARS AND CLUTCHES	30
1.6 COOLER CIRCUIT	30

2.0 SHIFT SELECTORS

2.1 DESCRIPTION OF AVAILABLE TYPES	31
2.2 OPERATION OF THE SHIFT SELECTOR	31
2.3 RANGE SELECTION—ALL 1000 AND 2000 PRODUCT FAMILIES TRANSMISSIONS WITH P (Park) POSITION	34
2.4 RANGE SELECTION—ALL 2000 PRODUCT FAMILY TRANSMISSIONS WITH PB (AUTO-APPLY PARKING BRAKE) POSITION	39
2.5 RANGE SELECTION—ALL 1000 AND 2000 PRODUCT FAMILIES TRANSMISSIONS WITHOUT EITHER P (PARK) OR PB (AUTO-APPLY PARKING BRAKE) POSITIONS.	42

3.0 DRIVING TIPS

3.1 MAXIMUM VEHICLE LOADING.	46
3.2 PREVENT MAJOR PROBLEMS	46
3.3 TURNING THE VEHICLE ON/OFF	47
3.4 ACCELERATOR CONTROL.	47
3.5 PRIMARY/SECONDARY SHIFT SCHEDULES	48
3.5.0.1 Allison LBSS (Load-Based Shift Scheduling)	48
3.6 KICKDOWN.	49
3.7 OUTPUT SPEED INDICATOR	49
3.8 DIAGNOSTIC CODES	49
3.9 RANGE INHIBIT(ED) LIGHT	49
3.9.0.1 Converter Over-temp Torque Protection COTP.	50
3.10 CHECK TRANSFORMER MALFUNCTION INDICATOR LIGHT (MIL)	51
3.11 DIAGNOSTIC CODES OVERVIEW.	51
3.12 SHIFT INHIBITS	51
3.12.1 Above-Idle Neutral-to-Range Shifts	52
3.12.2 Forward/Reverse Directional Shifts	52
3.12.3 Transmission Problems.	53
3.12.4 Auxiliary Equipment Operation.	53
3.13 USING THE ENGINE TO SLOW THE VEHICLE	53

3.14	RANGE PRESELECTION	54
3.14.1	Hold Upshift	55
3.14.2	Preselect Downshift.	55
3.15	REVERSE.	55
3.16	DRIVING ON SNOW OR ICE	55
3.17	ROCKING OUT.	56
3.18	OPERATING TEMPERATURES	56
3.19	HIGH FLUID TEMPERATURE.	57
3.20	PARKING BRAKE	58
3.21	PARK PAWL.	58
3.21.1	Torque Lock	59
3.22	PARKING/LEAVING VEHICLE WITH ENGINE RUNNING	60
3.23	TOWING OR PUSHING	61
3.24	SURGING NATURAL GAS ENGINES	61

4.0 PROGNOSTICS

4.1	1000 AND 2000 PRODUCT FAMILIES SERVICE PROGNOSTICS	62
4.2	OIL LIFE MONITOR	63
4.3	FILTER LIFE MONITOR	64
4.4	TRANSMISSION HEALTH MONITOR	64

5.0 CARE AND MAINTENANCE

5.1	PERIODIC INSPECTIONS AND CARE.	65
5.1.1	Transmission Inspection	65
5.1.2	Vehicle Inspection.	65
5.1.3	Welding	66
5.2	IMPORTANCE OF PROPER TRANSMISSION FLUID LEVEL	66
5.3	TRANSMISSION FLUID CHECK	67
5.3.1	Fluid Check Procedure	68
5.3.2	Cold Check Procedure	68
5.3.3	Hot Check Procedure.	69
5.3.4	Consistency of Reading	71
5.4	KEEPING FLUID CLEAN	71
5.5	FLUID RECOMMENDATIONS	71
5.6	TRANSMISSION FLUID AND FILTER CHANGE INTERVALS	72
5.6.1	Frequency	72
5.6.2	Abnormal Conditions	75
5.6.3	Fluid Analysis	75
5.7	TRANSMISSION FLUID CONTAMINATION	76
5.7.1	Fluid Examination	76
5.7.2	Water.	76
5.7.3	Engine Coolant	76
5.7.4	Metal	77
5.8	TRANSMISSION FLUID AND FILTER CHANGE PROCEDURE.	77

[Buy now](#)

[Allison Transmission 1000/2000 Operator's Manual PDF](#)

[With Instant Download](#)