



SpeedScrub Rider


Featuring



Foam Scrubbing Technology

and Hygenic™ Tanks

Service Information



331145
Rev. 00





This manual provides service information for the NOBLES SpeedScrub Rider machine.

This machine will provide excellent service. However, the best results will be obtained at minimum costs if:

- The machine is operated with reasonable care.
- The machine is maintained regularly - per the maintenance instructions provided.
- The machine is maintained with NOBLES supplied or approved parts.

Manual Number - 331145

Revision: 00

Published: 12-04

epcatalogs.com

Nobles and the FaST Foam Scrubbing Technology logo are United States registered trademarks of Tennant Company.

Copyright © 2004 NOBLES, Printed in U.S.A.

Table of Contents

Electrical Troubleshooting Information	1
Commonly Used Electrical Symbols & Terms.....	2
Ladder Schematic	3
Wire Harness Group.....	5
Key OFF, Operator NOT on Seat.....	9
Key OFF, Battery Charger Plugged In	10
Key ON, Operator on Seat	11
Tank Level Sensors.....	12
Horn & Hour Meter Systems	13
Propel Forward System.....	14
Propel Reverse System.....	15
Braking System	16
Scrub Head & Squeegee Actuator Systems	17
Scrub Brush Motors System.....	19
Vacuum Fan System	20
FaST System.....	21
Conventional Solution System.....	22
LED Locations & Descriptions.....	23
Operational Modes & Interlocks	24
Diagnostic & Fault Alarms	25
Alarm Codes	25
High Current Faults	25
Diagnostic & Configuration Modes	26
Display Software Revision Mode	27
Self Test Mode	28
Input Display Mode.....	29
Manual Mode.....	30
Propel / Brake Diagnostics	31
Battery Select Mode & Voltage Levels	32
Battery Select Mode	32
Voltage Levels.....	32
Reverse Alarm & Propel Speed Select Modes	33
Reverse Alarm Select Mode	33
Propel Speed Select Mode	33
Inputs & Outputs Table.....	34
Torque Standard.....	35
Inch Fasteners.....	35
METRIC Fasteners.....	37
Nylon Insert Lock Nuts	39
Nut-Hex Light THIN	39
Wheel Bolt and Nuts.....	40
Wheel Bearing Adjustment.....	40
Tightening Nuts on Tapered Shafts	41
Shoulder Bolts	42
Taper Lockr Bushings	43
Sequence Tightening	44

epcatalogs.com

ELECTRICAL

Troubleshooting Information

BEFORE CONDUCTING TESTS:

- * Read and Follow ALL Safety Warnings and Precautions in Operator's Manual
- * Always use an ESD (Electrostatic Discharge) strap when working near the Control Board
- * Be cautious when working near Control Board – Battery voltage is always present, even with Key OFF
- * Always unplug Positive Battery Cable when removing or replacing components

DURING TESTS:

- * Call Technical Services if Diagnostic Time Exceeds One Hour With Unknown Cause or Course of Action

NOTE: Troubleshooting charts may be shown with optional equipment. The optional equipment may not be specified in these charts. Some machines may not be equipped with all components shown.

[Buy now](#)

[Nobles NOMAD PDF Service Manual](#)

[With Instant Download](#)