

epcatalogs.com

3406

3408

3412

3416

3418

Corn Head

OPERATOR'S MANUAL

Part number 84172169

3rd edition English

July 2010

Replaces part number 87720369



Contents

1 GENERAL INFORMATION

Note to the Owner	1-1
Ecology and the Environment	1-2
Identification numbers Location	1-3

2 SAFETY INFORMATION

Personal safety	2-1
Precautionary Statements	2-2
Safety decals	2-3
Do Not Operate hang tag	2-7

3 TRANSPORT OPERATIONS

ROAD TRANSPORT

Transporting the machine	3-1
--------------------------------	-----

4 WORKING OPERATIONS

GENERAL INFORMATION

Operation	4-1
Deck Plates	4-2
Ear Savers	4-4
Divider Points	4-5
Crop Divider	4-9
Crop Deflector	4-11
Row unit operation	4-13
Operating speed	4-14
Auger Centering and Height	4-15
Deck plate Overview	4-18

5 MAINTENANCE

GENERAL INFORMATION

General Maintenance - Lubrication	5-1
Basic instructions - Maintenance	5-7
Gathering chain - Product overview	5-8
Gathering chain Tension adjustment - Basic instructions	5-9
Rolls - Product overview - Weed Knives	5-10
Auger drive system - Product overview	5-13
FEEDING Row unit - Product overview	5-15
Deck plate - Product overview	5-17

MAINTENANCE CHART

Fluids and lubricants - Lubricants List	5-20
Lubrication - Lubrication Schedule	5-21
Lubrication schedule	5-22
Maintenance schedule - Maintenance Schedule	5-23

STORAGE

End of season service	5-24
Preseason service	5-25

6 TROUBLESHOOTING

SYMPTOM(S)

Basic instructions - Troubleshooting Chart 6-1

7 SPECIFICATIONS

Machine Specifications 7-1

Torque Specifications - Minimum Hardware Tightening Torques for Normal Assembly Applications 7-3

Basic instructions - Chain Wear Tables - Roller Chains 7-7

8 ACCESSORIES

Optional Equipment 8-1

9 FORMS AND DECLARATIONS

Delivery report - Owner Copy 9-1

Delivery report - Dealer Copy 9-3

epcatalogs.com

epcatalogs.com



1 - GENERAL INFORMATION

Note to the Owner

This manual contains information concerning the adjustment and maintenance of your CASE IH Model 3400 Series Corn Head. You have purchased a dependable machine, but only by proper care and operation can you expect to receive the performance and long service built into this corn head. Please have all operators read this manual carefully and keep it available for ready reference.

This machine was designed to be mounted on and powered by a CASE IH combine. It is intended to convey crop into the CASE IH combine.

Your CASE IH dealer will instruct you in the general operation of your corn head, refer to the "Delivery Report" in this manual. Your dealer's staff of factory-trained service technicians will be glad to answer any questions that may arise regarding the operation of your corn head.

Your CASE IH dealer carries a complete line of genuine CNH service parts. These parts are manufactured and carefully inspected to insure high quality and accurate fitting of any necessary replacement parts. Be prepared to give your dealer the model and Product Identification Number (PIN) of the corn head when ordering parts. Locate these numbers now and record them below. Refer to the "General Information" section of this manual for the location of the model and PIN of your corn head.



Model

PIN

 **WARNING** 

THIS SAFETY ALERT SYMBOL INDICATES IMPORTANT SAFETY MESSAGES IN THIS MANUAL. WHEN YOU SEE THIS SYMBOL, CAREFULLY READ THE MESSAGE THAT FOLLOWS AND BE ALERT TO THE POSSIBILITY OF DEATH OR SERIOUS INJURY.

M171C

 **WARNING** 

Illustrations in this manual may show protective shields open or removed to better illustrate a particular feature or adjustment. However, be certain to close or replace all shields before operating the machine. Failure to comply could result in death or personal injury.

M1317

IMPROVEMENTS

CNH America LLC is continually striving to improve its products. We reserve the right to make improvements or changes when it becomes practical and possible to do so, without incurring any obligation to make changes or additions to the equipment sold previously.

[Buy now](#)

[Case 3406, 3408, 3412, 3416, 3418 Corn Head Set of Manuals PDF](#)

[With Instant Download](#)