Operation & Maintenance Manual



WARNING -

Unsafe use of this machine may cause serious injury or death. Operators and maintenance personnel must read this manual before operating or maintaining this machine. This manual should be kept near the machine for reference and periodically reviewed by all personnel who will come into contact with it.

NOTICE -

Komatsu has Operation & Maintenance Manuals written in some other languages. If a foreign language manual is necessary, contact your local distributor for availability.



FOREWORD



Komain in commends that any service parts used for maintenance, repair or replacement of emission control systems be genuine new Komatsu or lome tsu approved parts or Komatsu approved rebuilt parts or assemblies of their parts of equivalent quality, and that the engine be serviced by an authorized Komatsu distributor. Failure to follow these recommendations could result in ineffective service, damage to the product, or safety risks (including serious personal injury or death).

In the United States, the owner may choose to have maintenance, replacement or repair of the emissions-related parts performed by a facility other than an authorized Komatsu distributor.

CALIFORNIA Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

CALIFORNIA Proposition 65 Warning

Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer, birth defects and reproductive harm.

Wash hands after handling.

BEFORE READING THIS MANUAL (D65-0110-010-A-00-A)

This manual gives details of the operation and methods of inspection and maintenance for this machine that must be obeyed in order to use the machine safely. Most accidents are caused by the failure to follow fundamental safety rules for the operation and maintenance of machines.

Read, understand and follow all precautions and warnings in this manual and on the machine before performing operation and maintenance. Failure to do so may result in serious injury or death.

Komatsu cannot predict every circumstance that might involve a potential hazard when the machine is used. Therefore, the safety messages in this manual and on the machine may not include all possible safety precautions.


If you perform any operation, inspection, or maintenance under conditions that are not described in this manual, understand that it is your responsibility to take the necessary precautions to ensure safety. In no event you or others should engage in the prohibited uses or actions described in this manual. Improper operation and maintenance of the machine can be hazardous and could result in serious injury or death.

If you sell the machine, be sure to give this manual to the new owner together with the machine.

Always keep this Operation and Maintenance Manual in the location so we on the right so that all relevant personnel can read it at any time.

Operation and Maintenance Manual Storing Place

The storage pocket for the manual is provided on the backs the operator's seat back.



If this manual is lost or can ged, contact and tell your distributor about the machine model name and the serial No. immediately to arrange for its replacement. For details regarding the machine model name and the serial No., see the machine see al No. plate. In order to arrange the proper Operation and Maintenance Manual, you will need to provide the machine manual name and the serial No. to your Komatsu distributor.

This manuare each einternational units (SI) for units of measurement. For reference, units that have been used in the past are air air an in { }.

The explanations, values, and illustrations in this manual have been prepared based on the latest information available as of the date of its publication. Continuing improvements in the design of this machine may lead to additional changes that are not reflected in this manual. Consult Komatsu or your Komatsu distributor for the latest available information concerning your machine or with questions regarding information contained in this manual.

• The numbers in circles in the illustrations correspond to the numbers in () in the text. (Example: ① corresponds to (1))

Komatsu delivers machines that comply with all applicable regulations and standards of the country to which it has been shipped. If this machine has been purchased in another country, it may lack certain safety devices and specifications that are necessary for use in your country. If there is any question about whether your product complies with the applicable standards and regulations of your country, consult Komatsu or your Komatsu distributor before operating the machine.

FOREWORD SAFETY INFORMATION

SAFETY INFORMATION (ALL-1110-010-A-00-A)

To enable you to use the machine safely, and to prevent injury or death to operators, service personnel or bystanders, the precautions and warnings included in this manual and the safety signs attached to the machine must always be observed.

To identify important safety messages in the manual and on the machine labels, the following signal words are used.

The "Safety Alert Symbol" identifies important safety messages on machines, in manuals, and elsewhere. When you see this symbol, be alert to the risk of personal injury or death. Follow the instructions in the safety message.

A DANGER

This signal word indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

⚠ WARNING

This signal word indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



This signal word indicates a potential haz rdous situation exists which, if not avoided, may result in minor or moderate inj. v.

The following signal words are used to alert you to information that must be followed to avoid damage to the machine.

NOTICE REMARKS

Scorr

This precaution is given where the machine may be damaged or the service life reduced if the precaution is not followed.

This word is u ed in information that is useful to know.

<u>INTRODUCTION</u> FOREWORD

INTRODUCTION (PC-0000-001-K-00-A)


USE OF MACHINE (D65-0000-04H-K-00-A)

This Komatsu machine is designed to be used mainly for the following work:

- Dozing
- Leveling
- · Cutting into hard or frozen ground or ditching
- · Felling trees, removing stumps

See the section "RECOMMENDED APPLICATIONS (PAGE 3-180) " for further details.

DIRECTIONS OF MACHINE (D65-0000-04B-K-00-A)



In this manual, the directions with emachine (front, rear, left, right) are determined according to the view from the operator's seat in the directions of travel (front) of the machine.

- (A) Front
- (B) Rear
- (C) Left
- (D) Righ

- (E) Operator's seat
- (F) Sprocket

Buy now

Komatsu Bulldozer D65EX -17, D65PX-17, D65WX-17 Operation and Maintenance Manual PDF

With Instant Download