

Tigercat®

880 LOGGER

OPERATOR'S MANUAL

SERIAL NUMBER 8800101 TO 8800500



ISSUE 4.1, JULY 2014

Tigercat Industries Inc.

P.O. Box 637

Brantford, Ontario

Canada N3T 5P9

Tel: (519) 753-2000

Fax: (519) 753-8272

epcatalogs.com

Tigercat 880 LOGGER

TABLE OF CONTENTS

	SECTION
INTRODUCTION	v
STANDARDS, ROPS, FOPS, OPS, TOPS	vi
NON-APPROVED FIELD PRODUCT CHANGES.....	vii
SAFETY.....	1
CONTROLS AND OPERATION	2
LUBRICATION AND MAINTENANCE	3

CALIFORNIA

Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects and other reproductive harm.

880 Logger Available Literature

Operator's Manual, English (this manual)	Part No. 36952AENG
Service Manual English	Part No. 36953AENG
Parts Catalog.....	Part No. 36954A
Vehicle Moving and Transporting Instructions	Part No. 38452AMUL

epcatalogs.com

Tigercat 880 Logger

INTRODUCTION

An Operator's manual, Service manual and a Parts catalog are made available by **Tigercat** to assist the dealer, customer and operator in becoming familiar with the features of the 880 Loggers

Serial numbers:-

8800101 TO 8800500

The 880 Logger configured as a **Harvester** is designed for harvesting trees, at-the-stump processing or roadside processing applications in thinning, selective felling and clear felling applications in plantations and natural stands

or;

The 880 Logger configured as a **Loader** is designed for log processing, sorting, log transferring and loading.

or;

The 880 Logger configured as a **Shovel Logger** is designed for log transferring, loading, and shovel logging (hoe-chucking) by swinging logs closer to the road side minimizing ground surface impact and damage.

The operator's manual will assist the operator with the techniques of proper and safe operation of the 880 Logger. The service manual contains safety and servicing procedures and a preventive maintenance schedule to ensure optimum machine performance.

Section 1 in both the operator's manual and the service manual contains safety information that must be followed. As well, throughout the rest of the manuals, DANGER, WARNING and CAUTION notices are displayed where necessary, drawing attention to possible hazards when performing certain procedures.

Only trained personnel should be allowed to operate or work on the machine.

The information contained in this manual is current at time of printing. Improvements to the machine are on-going and may not be covered, therefore in these cases, contact your **Tigercat** dealer for the appropriate information.

The phrase "**and up**" appearing in this manual after the serial number implies that the related information is current for any machine serial number **greater** than the serial number preceding the "**and up**".

Tigercat reserves the right to make changes to the machine after this manual release date that may not immediately appear in this manual.

Every effort is made to send out updates on a regular basis. If the machine in question was built after the release date of this manual and there is a discrepancy, call Tigercat service department. The release date appears on the first page.

The Company reserves the right to change information contained herein at any time without prior notice.

Tigercat Industries Inc.

[Buy now](#)

[Tigercat Logger 880 Operator's Manual PDF](#)

[With Instant Download](#)