

Field Assembly Instruction

HYDRAULIC
EXCAVATOR

PC600-8E0

PC600LC-8E0

PC650-8E0

PC650LC-8E0

PC700LC-8E0

SERIAL NUMBERS 65001 and up

ecot3

KOMATSU

FOREWORD

Since this machine is large in size, it is divided into some units to meet the transportation conditions and regulations applied to the transportation route when shipped from our factory.

This manual describes how to assemble the units into the complete machine in the field. We hope that this machine will display its quality and you will use it safely according to the operation manual.


Many units are large in size and heavy in weight and may be handled in a dangerous place or posture and many workers may have to work together to sling them with cranes.

Accordingly, before starting the assembly work, the work supervisor is required to hold a safety meeting to oblige the workers to put on protective gear and appoint a work leader and a crane work signal man and allot roles to all the workers for safe work.

In particular, the above meeting is more important when workers of different languages and customs work together.

The following is a reference supervision system diagram.

(Instruction system)



When the work equipment is installed, the engine must be operated. Accordingly, before installing the work equipment, inspect and maintain the machine thoroughly.

Note that this manual does not describe the whole specification of the machine but describes only the basic specification.

If you have any question when dividing and transporting the machine by yourself in future, ask one of our distributors.

CONTENTS

Specifications	1
Precautions for Field Assembly	3
Disposal of Removed Parts	4
Assembling Procedures, Applicable Equipment and Schedule	5
KIT Layout Diagram	6
Transportation	7
List of Tools for Field Assembling	12
Tightening Torque	13
Coating Materials	18
Selection of Wire Ropes Used for Assembly	20
A. ASSEMBLY OF CHASSIS	21
A- 1. Installation of Left and Right Track Frames	22
A- 2. Installation of Travel Pipe	27
A- 3. Installation of Operator Cab's Left Handrail	32
A- 4. Installation of Operator Cab's Door Stopper and Striker	33
A- 5. Installation of Rearview Mirror	35
A- 6. Installation of Handrail	40
A- 7-1 Installation of Step	43
A- 7-2 Installation of Step	44
A- 8. Installation of Left Side Step	45
A- 9. Sticking Sheet to Counterweight	46
A-10. Installation of Rear View Camera	47
A-11. Installation of Counterweight	52
A-12. Installation of Stop Sign	54
A-13. Bleeding of Air from Travel Motor	56
A-14-1 Installation of Travel Piping Cover	57
A-14-2 Installation of Travel Piping Cover	61
A-15. Installation of Travel Motor Guard	64
A-16. Testing Track Shoe Tension	65
A-17. Check Fuel, Coolant and Oil Levels	68
B. ASSEMBLING OF WORK EQUIPMENT	71
B- 1. Assembly of Arm Cylinder	72
B- 2. Connection of Arm Cylinder Hoses	73
B- 3. Installation of Boom Cylinder	74
B- 4. Installation of Boom Cylinder Hoses	75
B- 5. Installation of Boom Foot Dust Seal	76
B- 6. Assembly of Boom Assembly	77
B- 7. Installation of Hoses from Chassis Along Top of Boom	78
B- 8. Connection of Boom Cylinder Head	80
B- 9. Installation of Arm Assembly	81
B-10. Installation of Bucket Cylinder Hoses between Boom and Bucket Cylinder	83
B-11. Installation of Bucket	84
B-12. Connection of Work Equipment Grease Piping	87
B-13. Connection of Work Equipment Wiring	88
B-14. Greasing after Assembling Work Equipment	90
B-15. Bleeding Air from Work Equipment Circuit	91
B-16. Parts to be Touched up After Field Assembly	92

C. Assembling of Work Equipment of Loading Shovel	93
C- 1. Releasing residual pressure in hydraulic circuit	94
C- 2. Pulling out boom foot pin and boom cylinder foot pin.....	95
C- 3. Installation of boom cylinder foot.....	96
C- 4. Installation of boom and arm assembly	97
C- 5. Installation of boom cylinder hoses	98
C- 6. Installation of boom cylinder rod pin.....	99
C- 7. Installation of boom cylinder	100
C- 8. Installation of arm cylinder hoses	101
C- 9. Installation of bucket cylinder	102
C-10. Installation of bucket cylinder hoses.....	103
C-11. Installation of connecting hoses between chassis and boom top.....	104
C-12. Installation of bottom dump cylinder hoses	105
C-13. Installation of bucket assembly	106
C-14. Installation of working lamps	108
C-15. Installation of work equipment grease piping	110
C-16. Greasing after assembling of work equipment	111
C-17. Bleeding air from work equipment circuit	112
C-18. Checking oil level in hydraulic tank and adding oil	113
D. ASSEMBLING OF COUNTERWEIGHT REMOVER	115
D- 1. Sticking Sheet to Counterweight	116
D- 2. Adjustment of Shims for Counterweight	117
D- 3. Greasing	122
D- 4. Installation of Counterweight Remover	123
D- 5. Installation of Cover	124
D- 6. Installation of Clamps	125
D- 7. Installation of Hoses	128
D- 8. Bleeding Air from Counterweight Remover Circuit.....	129
D- 9. Installation of Counterweight	130
D-10. Installation of Accessories	132
D-11. Check of operation	133
M. PROCEDURE FOR INSPECTION AND MAINTENANCE AFTER COMPLETION OF ASSEMBLY	135
M- 1. Inspection of Oil Level in Hydraulic Tank and Refill	136
M- 2. Replacement of Return Filter (Standard Filter to Flushing Filter)	138
M- 3. Flushing of Hydraulic Circuit	141
M- 4. Failure code	143
M- 5. Operating Method of Monitoring	148

Field Assembly Inspection Report (Backhoe)

Field Assembly Inspection Report (Loading Shovel)

epcatalogs.com

[Buy now](#)

[Komatsu Hydraulic Excavator PC600/LC-8E0, PC650/LC-8E0,
PC700LC-8E0 Field Assembly Instruction](#)

[With Instant Download](#)