



epcatalogs.com

SECTION AND GROUP CONTENTS

WORKSHOP MANUAL

SECTION 1 GENERAL INFORMATION

Group 1 Precautions for Disassembling and Assembling	
Group 2 Tightening	
Group 3 Painting	
Group 4 Bleeding Air	
Group 5 Pressure Release Procedure	
Group 6 Preparation	

SECTION 2 MAINTENANCE STANDARD

Group 1 Body	
Group 2 Travel System	
Group 3 Front Attachment	
Group 4 Front Attachment (Parallel Link)	

SECTION 3 BODY

Group 1 Cab	
Group 2 Counterweight	
Group 3 Center Hinge	
Group 4 Engine	
Group 5 Radiator Assembly	
Group 6 Hydraulic Oil Tank	
Group 7 Fuel Tank	
Group 8 Pump Device	
Group 9 Control Valve	
Group 10 Pilot Valve	
Group 11 Brake Charge Valve	
Group 12 Manifold Valve	
Group 13 Solenoid Valve	
Group 14 Priority Valve	
Group 15 Cooling Fan System	
Group 16 Ride Control Device	
Group 17 Exhaust Filter	
Group 18 Parallel Link (Special Parts)	

All information, illustrations and specifications in this manual are based on the latest product information available at the time of publication. The right is reserved to make changes at any time without notice.

(Blank)

epcatalogs.com

INTRODUCTION

To The Reader

This manual is written for an experienced technician to provide technical information needed to maintain and repair this machine.

- Be sure to thoroughly read this manual for correct product information and service procedures.

Additional References

Please refer to the other materials (operation and maintenance manual, parts catalog, engine technical material, Kawasaki shop materials, etc.) in addition to this manual.

Manual Composition

Our shop manuals consist of the Technical Manual, the Workshop Manual and the Engine Manual.

- Information included in the Technical Manual: Technical information needed for machine pre-delivery and delivery, operation and activation of all devices and systems, operational performance tests, and troubleshooting procedures.

- Information included in the Workshop Manual: Technical information needed for maintenance and repair of the machine, tools and devices needed for maintenance and repair, maintenance standards, and removal / installation and assembly / disassembly procedures.

- Information included in the Engine Manual: Technical information needed for machine pre-delivery and delivery and maintenance and repair of the machine, operation and activation of all devices and systems, troubleshooting and assembly / disassembly procedures.

Page Number

Each page has a number, located on the center lower part of the page, and each number contains the following information:

Example:

- Technical Manual: T 1-3-5

T	Technical Manual
1	Section Number
3	Group Number
5	Consecutive Page Number for Each Group


- Workshop Manual: W 1-3-2-5


W	Workshop Manual (Disassembly & Reassembly)
1	Section Number
3	Group Number
2	Sub Group Number
5	Consecutive Page Number for Each Group

INTRODUCTION


Safety Alert Symbol and Headline Notations

In this manual, the following safety alert symbol and signal words are used to alert the reader to the potential for personal injury of machine damage.

 This is the safety alert symbol. When you see this symbol, be alert to the potential for personal injury. Never fail to follow the safety instructions prescribed along with the safety alert symbol. The safety alert symbol is also used to draw attention to component/part weights. To avoid injury and damage, be sure to use appropriate lifting techniques and equipment when lifting heavy parts.

 **CAUTION:**
Indicated potentially hazardous situation which could, if not avoided, result in personal injury or death.

IMPORTANT:
Indicates a situation which, if not conformed to the instructions, could result in damage to the machine.

 **NOTE:**
Indicates supplementary technical information.


Units Used

SI Units (International System of Units) are used in this manual. MKSA (Meter, Kilogram, Second, Ampere) system units and English units are also indicated in parentheses just behind SI units.

Example: 24.5 MPa (250 kgf/cm², 3560 psi)

A table for conversion from SI units to other system units is shown below for reference purposes.

Quantity	To Convert From	Into	Multiply By
Length	mm	in	0.03937
	mm	ft	0.003281
Volume	L	US gal	0.2642
	L	US qt	1.057
	m ³	yd ³	1.308
Weight	kg	lb	2.205
Force	N	kgf	0.10197
	N	lbf	0.2248
Torque	N·m	kgf·m	0.10197
Pressure	MPa	kgf/cm ²	10.197
	MPa	psi	145.0
Power	kW	PS	1.360
	kW	HP	1.341
Temperature	°C	°F	°C×1.8+32
Velocity	km/h	mph	0.6214
	min ⁻¹	rpm	1.0
Flow rate	L/min	US gpm	0.2642
	mL/rev	cc/rev	1.0

 **NOTE:** The numerical value in this manual might be different from the above-mentioned table.

[Buy now](#)

[Kawasaki 67Z7B, 67TM7B Wheel Loader Shop Manual PDF](#)

[With Instant Download](#)